


IF55 LIN EC



EtherCAT®

in compliance with ETG.1000

- SSI to EtherCAT converter
- Suitable for SSI linear encoders
- Accepts MSB & LSB Aligned protocols up to 30 bits
- M12 connectors
- Implements the CoE protocol and the EtherCAT State Machine

Suitable for the following models:

- IF55 LIN EC

General Contents

1 - Safety summary	16
2 - Identification	17
3 - Mechanical installation	18
4 - Electrical connections	21
5 - Getting started	28
6 - Quick reference with TwinCAT	32
7 - EtherCAT® interface	53
8 - Default parameters list	94

This publication was produced by Lika Electronic s.r.l. 2022. All rights reserved. Tutti i diritti riservati. Alle Rechte vorbehalten. Todos los derechos reservados. Tous droits réservés.

This document and information contained herein are the property of Lika Electronic s.r.l. and shall not be reproduced in whole or in part without prior written approval of Lika Electronic s.r.l. Translation, reproduction and total or partial modification (photostat copies, film and microfilm included and any other means) are forbidden without written authorisation of Lika Electronic s.r.l.

The information herein is subject to change without notice and should not be construed as a commitment by Lika Electronic s.r.l. Lika Electronic s.r.l. reserves the right to make all modifications at any moments and without forewarning.

This manual is periodically reviewed and revised. As required we suggest checking if a new or updated edition of this document is available at Lika Electronic s.r.l.'s website. Lika Electronic s.r.l. assumes no responsibility for any errors or omissions in this document. Critical evaluation of this manual by the user is welcomed. Your comments assist us in preparation of future documentation, in order to make it as clear and complete as possible. Please send an e-mail to the following address info@lika.it for submitting your comments, suggestions and criticisms.

The logo for Lika Electronic s.r.l. consists of the word "lika" in a bold, lowercase, sans-serif font. The letter "i" has a dot, and the "a" has a tail that extends to the right.

General contents

User's guide.....	1
General contents.....	3
Subject Index.....	6
Typographic and iconographic conventions.....	7
Preliminary information.....	8
Glossary of EtherCAT terms.....	9
1 - Safety summary.....	16
1.1 Safety.....	16
1.2 Electrical safety.....	16
1.3 Mechanical safety.....	16
2 - Identification.....	17
3 - Mechanical installation.....	18
3.1 Overall dimensions.....	18
3.2 Installation on panel (Figure 2).....	18
3.3 Installation with DIN rail clip (Figure 3).....	19
4 - Electrical connections.....	21
4.1 Connection cap of the converter.....	21
4.2 SSI connector (Figure 4).....	22
4.3 EtherCAT interface and power supply connectors (Figure 4).....	23
4.4 Network configuration: topologies, cables, hubs, switches - Recommendations.....	23
4.5 Addressing.....	24
4.6 Line Termination.....	24
4.7 POWER SUPPLY DIP switch (Figure 6).....	25
4.8 Ground connection.....	25
4.9 Diagnostic LEDs.....	26
5 - Getting started.....	28
6 - Quick reference with TwinCAT.....	32
6.1 System configuration using TwinCAT software system from Beckhoff.....	32
6.1.1 Setting the Network Card.....	32
6.1.2 Add new I/O modules (Boxes).....	35
6.2 Setting the communication mode.....	39
6.2.1 Synchronous with SM3.....	39
6.2.2 Synchronous with DC (SYNCO).....	40
6.3 Process Data Objects.....	41
6.4 COE Object Dictionary.....	42
6.5 Online Data.....	43
6.6 EEPROM upgrade.....	44
6.7 Firmware upgrade.....	49
7 - EtherCAT® interface.....	53
7.1 Basic Information on EtherCAT® Protocol.....	53
7.1.1 Data transfer.....	54
7.1.2 ISO/OSI Layer model.....	55
7.1.3 Topology.....	55
7.1.4 Line Termination.....	56
7.1.5 Addressing.....	57
7.1.6 Communication mode.....	58

FreeRun.....	58
Synchronous with SM3.....	59
Synchronous with DC SYNC0.....	59
7.1.7 EtherCAT State Machine (ESM).....	60
7.1.8 Slave configuration.....	61
7.1.9 Timing and Synchronization.....	61
Sync Manager.....	62
Buffered Mode (3-Buffer Mode).....	62
Mailbox Mode (1-Buffer Mode).....	62
7.2 CANopen Over EtherCAT (CoE).....	64
7.2.1 XML file.....	64
7.2.2 Communication messages.....	65
7.2.3 Process Data Objects (PDO).....	65
7.2.4 Service Data Objects (SDO).....	65
7.2.5 Object dictionary.....	66
Communication Profile Area objects (DS301).....	68
1000-00 Device type.....	68
1008-00 Device Name.....	68
1009-00 Hardware version.....	68
100A-00 Software version.....	68
1010-01 Store parameters.....	68
1011-01 Restore default parameters.....	69
1018 Identity.....	69
01 Vendor ID.....	69
02 Product code.....	69
03 Revision.....	69
04 Serial number.....	70
1A00-01 PDO mapping parameter.....	70
01 Mapped Object 001.....	70
1C00 Sync Manager Communication Type.....	70
01 SM MailBox Receive (SM0).....	70
02 SM MailBox Send (SM1).....	71
03 SM PDO output (SM2).....	71
04 SM PDO input (SM3).....	71
1C12-00 Sync Manager RxPDO Assigned.....	71
1C13-01 Sync Manager TxPDO Assigned.....	71
01 Subindex 001.....	71
1C33 Sync Manager input parameter.....	71
01 Sync Type.....	71
02 Cycle time.....	72
03 Shift Time.....	72
04 Sync modes supported.....	72
05 Minimum cycle time.....	72
06 Calc and Copy time.....	72
Manufacturer Specific Profile Area objects.....	73
2200-00 Lika linear absolute sensor setting.....	73
No of SSI clocks.....	73
Max No of Information.....	73
SSI protocol.....	74
SSI output code.....	75
Bypass.....	75

2201-00 Lika linear absolute sensor resolution.....	76
Standardised Profile Area objects (DS406).....	77
6000-00 Operating parameters.....	77
Scaling function.....	77
Code sequence.....	78
6001-00 Total measuring range.....	79
6002-00 Total measuring range.....	81
6003-00 Preset.....	82
6004-00 Position value.....	83
6005-00 Measuring step setting.....	84
6005-01 Position step setting.....	85
6500-00 Operating status.....	88
Scaling.....	88
Counting direction.....	88
6501-00 Measuring step.....	89
6502-00 Number of revolutions.....	89
6503-00 Errors.....	89
6504-00 Supported errors.....	89
6505-00 Warnings.....	89
6506-00 Supported warnings.....	89
6509-00 Offset.....	90
7.2.6 SDO Abort codes.....	91
7.2.7 Emergency Error Codes.....	92
7.2.8 AL Status Error Codes.....	92
8 – Default parameters list.....	94

Subject Index

1		
1000-00 Device type.....	68	
1008-00 Device Name.....	68	
1009-00 Hardware version.....	68	
100A-00 Software version.....	68	
1010-01 Store parameters.....	68	
1011-01 Restore default parameters.....	69	
1018 Identity.....	69	
1A00-01 PDO mapping parameter.....	70	
1C00 Sync Manager Communication Type.....	70	
1C12-00 Sync Manager RxPDO Assigned.....	71	
1C13-01 Sync Manager TxPDO Assigned.....	71	
1C33 Sync Manager input parameter.....	71	
2		
2200-00 Lika linear absolute sensor setting.....	73	
2201-00 Lika linear absolute sensor resolution..	76	
6		
6000-00 Operating parameters.....	77	
6001-00 Total measuring range.....	79	
6002-00 Total measuring range.....	81	
6003-00 Preset.....	82	
6004-00 Position value.....	83	
6005-00 Measuring step setting.....	84	
6005-01 Position step setting.....	85	
6500-00 Operating status.....	88	
6501-00 Measuring step.....	89	
6502-00 Number of revolutions.....	89	
6503-00 Errors.....	89	
6504-00 Supported errors.....	89	
6505-00 Warnings.....	89	
6506-00 Supported warnings.....	89	
6509-00 Offset.....	90	
B		
BOOTSTRAP.....	60	
Bypass.....	75	
C		
Calc and Copy time.....	72	
Code sequence.....	78	
Counting direction.....	88	
Cycle time.....	72	
D		
Diagnostic data.....	92	
H		
Hardware error.....	92	
I		
INIT.....	60	
M		
Mapped Object 001.....	70	
Max No of Information.....	73	
Minimum cycle time.....	72	
N		
No of SSI clocks.....	73	
O		
OPERATIONAL.....	60	
P		
PRE-OPERATIONAL.....	60	
Product code.....	69	
R		
Revision.....	69	
S		
SAFE-OPERATIONAL.....	60	
Scaling.....	88	
Scaling function.....	77	
Serial number.....	70	
Shift Time.....	72	
SM MailBox Receive (SM0).....	70	
SM MailBox Send (SM1).....	71	
SM PDO input (SM3).....	71	
SM PDO output (SM2).....	71	
SSI output code.....	75	
SSI protocol.....	74	
Subindex 001.....	71	
Sync modes supported.....	72	
Sync Type.....	71	
V		
Vendor ID.....	69	

Typographic and iconographic conventions

In this guide, to make it easier to understand and read the text the following typographic and iconographic conventions are used:

- parameters and objects both of the device and the interface are coloured in **GREEN**;
- alarms are coloured in **RED**;
- states are coloured in **FUCSIA**.

When scrolling through the text some icons can be found on the side of the page: they are expressly designed to highlight the parts of the text which are of great interest and significance for the user. Sometimes they are used to warn against dangers or potential sources of danger arising from the use of the device. You are advised to follow strictly the instructions given in this guide in order to guarantee the safety of the user and ensure the performance of the device. In this guide the following symbols are used:

	This icon, followed by the word WARNING , is meant to highlight the parts of the text where information of great significance for the user can be found: user must pay the greatest attention to them! Instructions must be followed strictly in order to guarantee the safety of the user and a correct use of the device. Failure to heed a warning or comply with instructions could lead to personal injury and/or damage to the unit or other equipment.
	This icon, followed by the word NOTE , is meant to highlight the parts of the text where important notes needful for a correct and reliable use of the device can be found. User must pay attention to them! Failure to comply with instructions could cause the equipment to be set wrongly: hence a faulty and improper working of the device could be the consequence.
	This icon is meant to highlight the parts of the text where suggestions useful for making it easier to set the device and optimize performance and reliability can be found. Sometimes this symbol is followed by the word EXAMPLE when instructions for setting parameters are accompanied by examples to clarify the explanation.

Preliminary information

This guide is designed to provide the most complete and exhaustive information the operator needs to correctly and safely install and operate the **SSI to EtherCAT gateways of the IF55 series**.

IF55 series gateways allow the **integration of SSI encoders**, both rotary and linear, **into conventional fieldbuses or industrial Ethernet networks**.

The present manual is specifically designed to describe the SSI to EtherCAT IF55 model for linear encoders (order code IF55 LIN EC). For information on the SSI to EtherCAT IF55 model for rotary encoders (order code IF55 ROT EC) refer to the specific documentation.

For information on the gateways designed for the integration of other fieldbus encoders (SSI to Profibus: order codes IF55 ROT PB and IF55 LIN PB; and SSI to CANopen: order codes IF55 ROT CB and IF55 LIN CB), refer to the specific documentation.

Please note that the present manual does not prescind from the user's guide of the SSI encoder the gateway has to be connected to. Please read carefully the encoder's documentation before installing, connecting and operating the measuring system.

For detailed technical specifications please refer also to the product datasheet.

To make it easier to read the text, this guide can be divided into two main sections.

In the first section general information concerning the safety, the mechanical installation and the electrical connection as well as tips for setting up and running properly and efficiently the unit are provided.

In the second section, entitled **EtherCAT Interface**, both general and specific information is given on the EtherCAT interface. In this section the interface features and the objects implemented in the unit are fully described.

Glossary of EtherCAT terms

EtherCAT, like many other networking systems, has a set of unique terminology. Table below contains a few of the technical terms used in this guide to describe the EtherCAT interface. They are listed in alphabetical order.

Acknowledge telegram (AT)	Telegram, in which each Slave inserts its data.
Actual value	Value of a variable at a given instant.
Algorithm	Completely determined finite sequence of operations by which the values of the output data can be calculated from the values of the input data.
Application	Function or data structure for which data is consumed or produced. Software functional element specific to the solution of a problem in industrial-process measurement and control.
Application class	Configuration of a Drive Object with a set of functional objects and supported by standard telegrams.
Application mode	Type of application that can be requested from a PDS.
Application objects	Multiple object classes that manage and provide a run time exchange of messages across the network and within the network device.
Application process	Part of a distributed application on a network, which is located on one device and unambiguously addressed.
Application relationship	Cooperative association between two or more application-entity-invocations for the purpose of exchange of information and coordination of their joint operation. This relationship is activated either by the exchange of application-protocol-data-units or as a result of preconfiguration activities.
Attribute	Description of an externally visible characteristic or feature of an object, property or characteristic of an entity. The attributes of an object contain information about variable portions of an object. Typically, they provide status information or govern the operation of an object. Attributes may also affect the behaviour of an object. Attributes are divided into class attributes and instance attributes.
Axis	Logical element inside an automation system (e.g. a motion control system) that represents some form of movement.
Basic Slave	Slave device that supports only physical addressing of data.
Behaviour	Indication of how an object responds to particular events.
Bit	Unit of information consisting of a 1 or a 0. This is the smallest data unit that can be transmitted.

CANopen	Application layer protocol as defined in EN 50325-4.
Channel	Representation of a single physical or logical management object of a Slave to control conveyance of data.
CIP™	Common Industrial Protocol (see IEC 61158 Type 2, IEC 61784-1 and IEC 61784-2 CPF2).
Class	Description of a set of objects that share the same attributes, operations, methods, relationships, and semantics.
Client	Object which uses the services of another (Server) object to perform a task. Initiator of a message to which a Server reacts.
Clock synchronization	Representation of a sequence of interactions to synchronize the clocks of all time receivers by a time Master.
Commands	Set of commands from the application control program to the PDS to control the behaviour of the PDS or functional elements of the PDS.
Communication cycle	Accumulation of all telegrams between two Master synchronization telegrams.
Communication object	Component that manages and provides a run time exchange of messages across the network.
Connection	Logical binding between two application objects within the same or different devices.
Consume	Act of receiving data from a provider.
Consumer	Node or sink receiving data from a provider.
Control	Purposeful action on or in a process to meet specified objectives.
Control device	Physical unit that contains – in a module/subassembly or device – an application program to control the PDS.
Control unit	Control device.
Control word	Two adjacent bytes inside the Master data telegram containing commands for the addressed drive.
Controller	Controlling device which is associated with one or more drives (axes) a host for the overall automation.
Conveyance path	Unidirectional flow of APDUs across an application relationship.
Cycle time	Time span between two consecutive cyclically recurring events.
Cyclic	Events which repeat in a regular and repetitive manner.
Cyclic data	Part of the telegram which does not change its meaning during cyclic operation of the interface. High priority real-time data that is transferred by a CIP Motion connection on a periodic basis.
Data	Generic term used to refer to any information carried over a

	fieldbus.
Data consistency	Means for coherent transmission and access of the input-or-output-data object between and within Client and Server.
Data exchange	Demand dependent; non cyclic transmission (service channel).
Data type	Relation between values and encoding for data of that type according to the definitions of IEC 61131-3. Set of values together with a set of permitted operations.
Data type object	Entry in the object dictionary indicating a data type.
Default gateway	Device with at least two interfaces in two different IP subnets acting as router for a subnet.
Device	Field device. Networked independent physical entity of an industrial automation system capable of performing specified functions in a particular context and delimited by its interfaces. Entity that performs control, actuating and/or sensing functions and interfaces to other such entities within an automation system. Physical entity connected to the fieldbus composed of at least one communication element (the network element) and which may have a control element and/or a final element (transducer, actuator, etc.).
Device profile	Collection of device dependent information and functionality providing consistency between similar devices of the same device type. Representation of a device in terms of its parameters and behaviour according to a device model that describes the device's data and behaviour as viewed through a network, independent from any network technology.
Diagnosis information	All data available at the Server for maintenance purposes.
Distributed clocks	Method to synchronize Slaves and maintain a global time base.
DL	Data-link-layer.
DLPDU	Data-link-protocol-data-unit.
Drive Object	Functional element of a Drive Unit.
Drive Unit	Logical device which comprises all functional elements related to one central processing unit.
Error	Discrepancy between a computed, observed or measured value or condition and the specified or theoretically correct value or condition.
Error class	General grouping for related error definitions and corresponding error codes.
Error code	Identification of a specific type of error within an error class.
EtherCAT State Machine	EtherCAT Slave is a state machine; communication and operating characteristics depend on the current state of the

	device.
Event	Instance of a change of conditions.
Event data	Medium priority real-time data that is transferred by a CIP Motion connection only after a specified event occurs.
Feed forward	Command value used to compensate the lag in the control loop.
Feedback variable	Variable which represents a controlled variable and which is returned to a comparing element.
Fieldbus memory management unit	Function that establishes one or several correspondences between logical addresses and physical memory.
Fieldbus memory management unit entity	Single element of the fieldbus memory management unit: one correspondence between a coherent logical address space and a coherent physical memory location.
Frame	Denigrated synonym for DLPDU.
FreeRun	Asynchronous communication mode.
Full Slave	Slave device that supports both physical and logical addressing of data.
Functional element	Entity of software or software combined with hardware, capable of accomplishing a specified function of a device.
HMI	Human Machine Interface.
Host	Device that covers the automation functionality of an automation device.
I/O data	Input data and output data that would typically need to be updated on a regular basis (e.g. periodic change of state), such as commands, set-points, status and actual values.
Identification number (IDN)	Designation of operating data under which a data block is preserved with its attribute, name, unit, minimum and maximum input values, and the data.
Index	Address of an object within an application process.
Input data	Data transferred from an external source into a device, resource or functional element.
Interface	Shared boundary between two entities defined by functional characteristics, signal characteristics, or other characteristics as appropriate.
Little endian	Data representation of multi-octet fields where the least significant octet is transmitted first.
Logical power drive system	Model which includes PDS and communication network accessible through the generic PDS interface.
Mapping	Correspondence between two objects in that way that one object is part of the other object.
Mapping parameters	Set of values defining the correspondence between application objects and process data objects.

Master	Device that controls the data transfer on the network and initiates the media access of the Slaves by sending messages and that constitutes the interface to the control system. Node, which assigns the other nodes the right to transmit.
Master data telegram (MDT)	Telegram, in which the Master inserts its data.
Medium	Cable, optical fibre or other means by which communication signals are transmitted between two or more points.
Message	Ordered series of octets intended to convey information. Normally used to convey information between peers at the application layer.
Model	Mathematical or physical representation of a system or a process, based with sufficient precision upon known laws, identification or specified suppositions.
Motion	Any aspect of the dynamics of an axis.
Motion Axis Object	Object that defines the attributes, services, and behaviour of a motion device based axis (or PDS) according to the CIP Motion specification, including Communications, Device Control, and Basic Drive FE elements as defined in IEC 61800-7.
Network	Set of nodes connected by some type of communication medium, including any intervening repeaters, bridges, routers and lower-layer gateways.
Node	Single DL-entity as it appears on one local link. End-point of a link in a network or a point at which two or more links meet [derived from IEC 61158-2].
Object	Abstract representation of a particular component within a device. An object can be: <ol style="list-style-type: none"> 1. an abstract representation of the capabilities of a device. Objects can be composed of any or all of the following components: <ul style="list-style-type: none"> ○ data (information which changes with time); ○ configuration (parameters for behaviour); ○ methods (things that can be done using data and configuration); 2. a collection of related data (in the form of variables) and methods (procedures) for operating on that data that have clearly defined interface and behaviour.
Object dictionary	Data structure addressed by Index and Sub-index that contains description of data type objects, communication objects and application objects. List of objects with unique 16-bit index and 8-bit sub-index as defined in EN 50325-4.
Operating cycle	Period of the control loop within the drive or the control unit.
Operating mode	Characterization of the way and the extent to which the human operator intervenes in the control equipment.

Output data	Data originating in a device, resource or functional element and transferred from them to external systems.
P-Device	Field device and the host for the Drive Objects.
Parameter	Data element that represents device information that can be read from or written to a device, for example through the network or a local HMI.
PDO	Process Data Object.
PDS	Power Drive System.
Process data	Collection of application objects designated to be transferred cyclically or acyclically for the purpose of measurement and control.
Process Data Object (PDO)	Communication object with real-time capability. Structure described by mapping parameters containing one or several process data entities.
Producer	Node or source sending data to one or many consumers.
Profile	Representation of a PDS interface in terms of its parameters, parameter assemblies and behaviour according to a communication profile and a device profile.
Protocol	Convention about the data formats, time sequences, and error correction in the data exchange of communication systems.
Reference variable	Input variable to a comparing element in a controlling system which sets the desired value of the controlled variable and is deducted from the command variable.
Resource	Processing or information capability.
Segment	Collection of one real Master with one or more Slaves.
Server	Object which provides services to another (Client) object.
Service	Operation or function than an object and/or object class performs upon request from another object and/or object class.
Service data	Lower priority real-time data associated with a service message from the controller that is transferred by a CIP Motion connection on a periodic basis.
Set-point	Value or variable used as output data of the application control program to control the PDS.
Slave	DL-entity accessing the medium only after being initiated by the preceding Slave or the Master. Node, which is assigned the right to transmit by the Master.
Standard telegram	Set of input data and output data for an application mode.
Status	Set of information from the PDS to the application control program reflecting the state or mode of the PDS or a functional element of the PDS.
Status word	Two adjacent bytes inside the drive telegram containing status information.

Subindex	Sub-address of an object within the object dictionary.
Supervisor	Engineering device which manages provisions of configuration data (parameter sets) and collections of diagnosis data from P-Devices and/or controllers.
Switch	MAC bridge as defined in IEEE 802.1D.
Sync Manager	Sync Manager has the task of synchronizing data transfer between Master and Slave and prevents the same memory area from being written by different events. Collection of control elements to coordinate access to concurrently used objects.
Sync manager channel	Single control elements to coordinate access to concurrently used objects.
Synchronised	Condition where the local clock value on the drive is locked onto the Master clock of the distributed System Time.
Synchronous with DC SYNC0	In this operating mode data is sampled and then copied into Sync Manager buffer simultaneously at SYNC0 event generated by the ESC capture/compare unit.
Synchronous with SM3	In this mode data is sampled and then copied into Sync Manager buffer as soon as previous data was read from the Master (SM event); in this way new sampled data is synchronous with Master readings.
System Time	Absolute time value as defined in the CIP Sync specification in the context of a distributed time system where all devices have a local clock that is synchronised with a common Master clock.
Telegram	Message.
Time stamp	System Time stamp value associated with the CIP Motion connection data that conveys the absolute time when the associated data was captured, or that can also be used to determine when the associated data shall be applied.
Topology	Physical network architecture with respect to the connection between the stations of the communication system.
Type	Hardware or software element which specifies the common attributes shared by all instances of the type.
Use case	Class specification of a sequence of actions, including variants, that a system (or other entity) can perform, interacting with actors of the system.
Variable	Software entity that may take different values, one at a time.

1 – Safety summary



1.1 Safety

- Always adhere to the professional safety and accident prevention regulations applicable to your country during device installation and operation;
- installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and stationary mechanical parts;
- device must be used only for the purpose appropriate to its design: use for purposes other than those for which it has been designed could result in serious personal and/or the environment damage;
- high current, voltage and moving mechanical parts can cause serious or fatal injury;
- warning ! Do not use in explosive or flammable areas;
- failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment;
- Lika Electronic assumes no liability for the customer's failure to comply with these requirements.



1.2 Electrical safety

- Turn off the power supply before connecting the device;
- connect according to the explanation in the "4 - Electrical connections" section on page 21;
- in compliance with the 2014/30/EU norm on electromagnetic compatibility, the following precautions must be taken:
 - before handling and installing, discharge electrical charge from your body and tools which may come in touch with the device;
 - power supply must be stabilized without noise, install EMC filters on device power supply if needed;
 - always use shielded cables (twisted pair cables whenever possible);
 - avoid cables runs longer than necessary;
 - avoid running the signal cable near high voltage power cables;
 - mount the device as far as possible from any capacitive or inductive noise source, shield the device from noise source if needed;
 - to guarantee a correct working of the device, avoid using strong magnets on or near by the unit;
 - minimize noise by connecting the shield and/or the connector housing and/or the frame to ground. Make sure that ground is not affected by noise. The connection point to ground can be situated both on the device side and on user's side. The best solution to minimize the interference must be carried out by the user. Provide the ground connection as close as possible to the unit. We suggest using the ground point provided in the connection cap (use one TCEI M3 x 6 cylindrical head screw with two tooth lock washers).



1.3 Mechanical safety

- Install the device following strictly the information in the "3 - Mechanical installation" section on page 18;
- mechanical installation has to be carried out with power supply disconnected and stationary mechanical parts;
- do not disassemble the unit unless otherwise indicated in the document;
- do not tool the unit unless otherwise indicated in the document;
- delicate electronic equipment: handle with care; do not subject the device to knocks or shocks;
- respect the environmental characteristics declared by manufacturer.

2 - Identification

The device can be identified through the **order code** and the **serial number** printed on the label applied to its enclosure. Information is listed in the delivery document too. Please always quote the order code and the serial number when reaching Lika Electronic for purchasing spare parts or needing assistance. For any information on the technical characteristics of the product refer to the technical catalogue.



Warning: devices having order code ending with "/Sxxx" may have mechanical and electrical characteristics different from standard and be supplied with additional documentation for special connections (Technical info).

3 - Mechanical installation



WARNING

Installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and mechanical parts compulsorily in stop.

3.1 Overall dimensions

(values are expressed in mm)




Figure 1

3.2 Installation on panel (Figure 2)




Figure 2

The unit is designed for installation on the even surface of a panel.
 The back flange **2** is fitted with four holes for inserting the fixing screws **1**. Tighten the four fixing screws **1** until the unit is properly fastened to the support. Use **four M3 8 mm min. long cylinder head screws**. The recommended tightening torque is **1.1 Nm**.

3.3 Installation with DIN rail clip (Figure 3)

The unit can be installed on DIN profiles inside a rack. A clip **3** for direct fitting on DIN TS35 rails is supplied for free. It has to be fixed on the back of the flange **2** by means of the provided screw **4**.



WARNING

To mount the clip **3** you need to remove the cap **5** and drill a hole **A** in the back flange **2**. Delicate electronic circuits and wirings are located inside the cap **5**. Thus this operation has to be accomplished by skilled personnel only. Please pay careful attention and observe great precaution when carrying out this operation.




Figure 3

- Loosen the two screws **6** that fasten the cap **5** to the back flange **2**;

**WARNING**

Please note that, for graphical clarity, we show the cap **5** completely removed from the back flange **2**. Actually the parts are not be fully separated because of the internal wirings.

- open the cap **5** and separate it from the flange **2** as much as possible; please pay attention to the internal wirings;
- drill a 4.5 mm diameter hole **A** in the flange **2**; use the notch in the inside of the flange **2** to guide the drill bit;

**WARNING**

Carefully remove the scrap material after drilling.

- mount the clip **3** on the back of the flange **2** and fix it by means of the provided M4 x 8 screw **4**; it has to be screwed on the inner side of the flange **2**;
- replace the cap **5** and fix it by means of the screws **6**.

4 - Electrical connections



WARNING

Installation, electrical connection and maintenance operations must be carried out by qualified personnel only, with power supply disconnected. Mechanical components must be in stop.




Figure 4

4.1 Connection cap of the converter



WARNING

Do not remove or mount the connection cap with power supply switched ON. Damage may be caused to internal components.

The DIP switch meant to set the voltage level of the power supply to be provided to the connected encoder is located inside the connection cap. Thus you must remove the connection cap to access it.



NOTE

Be careful not to damage the internal components when you perform this operation.

To remove the connection cap loosen the two screws **1**. Please be careful with the internal connector.

Always replace the connection cap at the end of the operation. Take care in re-connecting the internal connector. Tighten the screws **1** using a tightening torque of approx. 2.5 Nm.



WARNING

You are required to check that the converter back flange and the connection cap are at the same potential before replacing the connection cap!




Figure 5 - Removing the connection cap

4.2 SSI connector (Figure 4)

The connection cap is fitted with one M12 8-pin female connector to network the IF55 gateway and the SSI encoder.

M12 8-pin (frontal side)	SSI connection
	<p>A coding female</p>
Pin	Description
1	0Vdc power supply
2	+Vdc power supply *
3	Clock OUT +
4	Clock OUT -
5	Data IN +
6	Data IN -
7 and 8	not connected

* The power supply voltage level must be set through the POWER SUPPLY DIP switch located inside the enclosure of the converter, see the "4.7 POWER SUPPLY DIP switch (Figure 6)" section on page 25.



WARNING

The max. length of the SSI cable must not exceed 30 m / 98.425 ft.

4.3 EtherCAT interface and power supply connectors (Figure 4)

The connection cap is fitted with three M12 4-pin connectors with pin-out in compliance with the EtherCAT® standard. Therefore you can use standard EtherCAT cables commercially available.

Please note that input ECATIN (BUS IN) and output ECATOUT (BUS OUT) connectors are not interchangeable! BUS IN connector must be networked towards the EtherCAT Master.

The Ethernet interface supports 100 Mbit/s, fast Ethernet, full duplex operation.

M12 4-pin (frontal side)	BUS IN & BUS OUT	POWER SUPPLY
	<p>D coding female</p>	<p>A coding male</p>

Pin	Description	Description
1	Tx Data +	+10Vdc +30Vdc power supply
2	Rx Data +	not connected
3	Tx Data -	0Vdc power supply
4	Rx Data -	not connected

4.4 Network configuration: topologies, cables, hubs, switches - Recommendations

Cables and connectors comply with the EtherCAT specifications. Cables are CAT-5 shielded cables.

Line, tree or star: EtherCAT supports almost any topology. The bus or line structure known from the fieldbuses thus also becomes available for Ethernet, without the quantity limitations implied by cascaded switches or hubs.

The Fast Ethernet physics (100BASE-TX) enables a cable length of 100 m (328 ft) between two devices. Since up to 65,535 devices can be connected, the size of the network is almost unlimited.

The Ethernet protocol according to IEEE 802.3 remains intact right up to the individual device; no sub-bus is required. In order to meet the requirements of a modular device like an electronic terminal block, the physical layer in the coupling device can be converted from twisted pair or optical fiber to LVDS

(alternative Ethernet physical layer, standardized in [4.5]). A modular device can thus be extended very cost-efficiently. Subsequent conversion from the backplane physical layer LVDS to the 100BASE-TX physical layer is possible at any time – as usual with Ethernet.

For a complete list of the available cordsets and connection kits please refer to the product datasheet ("Accessories" list).

4.5 Addressing

It is not necessary to assign a physical address to the device because the addressing of the Slave is automatic at power-on during the initial scanning of the hardware configuration.

The field for addressing is 32-bit long, there are three kinds of addressing:

- Auto Increment Addressing = Position Addressing: 16 bits indicate the physical position of the Slave inside the network while 16 bits are scheduled for local memory addressing; when the Slave receives the frame then it increments the position address and the Slave receiving address 0 is the addressed device;
- Fixed Addressing = 16 bits indicate the physical address of the Slave inside the network while 16 bits are scheduled for addressing the local memory;
- Logical Address = the Slave is not provided with its own individual address, but it can read and write data in a section of the total memory space available (4 Gigabytes).

For complete information refer to the "7.1.5 Addressing" section on page 57.

4.6 Line Termination

EtherCAT network needs no line termination because the line is terminated automatically; in fact every Slave is able to detect the presence of the downstream Slaves. For complete information refer to the "7.1.4 Line Termination" section on page 56.

4.7 POWER SUPPLY DIP switch (Figure 6)



WARNING

Power supply must be turned off before performing this operation!

The power supply voltage level to be provided to the connected encoder must be set through the POWER SUPPLY DIP switch located inside the enclosure of the converter. It must be according to the power supply voltage level required by the connected SSI encoder. To access the POWER SUPPLY DIP switch refer to the "4.1 Connection cap of the converter" section on page 21.

Set the POWER SUPPLY DIP switch to UP position to provide +10Vdc +30Vdc power supply voltage level to the encoder (default setting); set the POWER SUPPLY DIP switch to DOWN position to provide +5Vdc $\pm 5\%$ power supply voltage level to the encoder.



Figure 6

4.8 Ground connection

To minimize noise connect properly the shield and/or the connector housing and/or the frame to ground. Connect properly the cable shield to ground on user's side. Lika's EC- pre-assembled cables are fitted with shield connection to the connector ring nut in order to allow grounding through the body of the device. Lika's E- connectors have a plastic gland, thus grounding is not possible. If metal connectors are used, connect the cable shield properly as recommended by the manufacturer. Anyway make sure that ground is not affected by noise. It is recommended to provide the ground connection as close as possible to the

device. We suggest using the ground point provided in the cap (see Figure 4, use 1 TCEI M3 x 6 cylindrical head screw with 2 tooth lock washers).

4.9 Diagnostic LEDs

Five LEDs located in the rear side of the connection cap are designed to show the operating or fault status of the EtherCAT® interface.

The LEDs operation is according to the EtherCAT specifications, see ETG1300_S_R_V1i1i0_IndicatorLabelingSpecification.pdf.

LED states	Definition
ON	The indicator shall be constantly ON.
OFF	The indicator shall be constantly OFF.
Flickering	The indicator shall turn ON and OFF iso-phase with a frequency of 10 Hz: ON for 50 ms and OFF for 50 ms.
Blinking	The indicator shall turn ON and OFF iso-phase with a frequency of 2.5 Hz: ON for 200 ms followed by OFF for 200 ms.
Single flash	The indicator shall show one short flash (200 ms) followed by a long OFF phase (1000 ms).
Double flash	The indicator shall show a sequence of two short flashes (200 ms), separated by an OFF phase (200 ms), and followed by a long OFF phase (1000 ms).

LED	Meaning
-----	---------

L/A Link/ Activity (yellow)	It shows the current state of the physical links (IN and OUT) and the activity in the links
OFF	condition: port closed, link: YES, activity: N.A.
FLICKERING	condition: port open, link: YES, activity: YES
ON	condition: port open, link: YES, activity: NO

RUN (green)	It shows the current state of the EtherCAT State Machine (ESM)
OFF	The encoder is in INIT state
BLINKING	The encoder is in PRE-OPERATIONAL state
SINGLE FLASH	The encoder is in SAFE-OPERATIONAL state
ON	The encoder is in OPERATIONAL state
FLICKERING	The encoder is in BOOT state

PWR (green)	It shows the current state of power supply
OFF	The encoder power supply is switched OFF
ON	The encoder power supply is switched ON

ERR (red)	It shows the current error state
OFF	No error
FLICKERING	Error while loading parameters from flash memory at

	start-up; encoder parameters have not been saved correctly on flash memory
BLINKING	Invalid configuration
SINGLE FLASH	Local error (see ETG1000.6, "EtherCAT Specification - Part 6")
DOUBLE FLASH	Watchdog timeout
ON	Memory error and ESC controller not active

5 – Getting started



The following instructions are provided to allow the operator to set up the device for standard operation in a quick and safe mode.

- Mechanically install the device (see on page 18);
- perform the electrical and network connections (see on page 21);
- you do not need to set the node address and the transmission rate (see on page 57);
- you do not need to set any line termination (see on page 56);
- switch on the +10Vdc +30Vdc power supply;
- set the characteristics of the connected SSI encoder:
 - set the number of SSI clocks next to the **No of SSI clocks** parameter in the **2200-00 Lika linear absolute sensor setting** object;
 - set the output code used to arrange the output information next to the **SSI output code** parameter in the **2200-00 Lika linear absolute sensor setting** object;
 - set the protocol used to arrange the absolute information next to the **SSI protocol** parameter in the **2200-00 Lika linear absolute sensor setting** object;
 - set the physical resolution of the SSI encoder next to the **2201-00 Lika linear absolute sensor resolution** object; the **6005-01 Position step setting** and **6501-00 Measuring step** objects are automatically set accordingly;
 - set the max. number of information the SSI encoder can output for the max. measuring range next to the **Max No of Information** parameter in the **2200-00 Lika linear absolute sensor setting** register;
- the **6001-00 Total measuring range** and **6002-00 Total measuring range** objects are automatically set according to the value in the **Max No of Information** parameter; the user can set a custom measuring range;
- if you want to use the physical resolution (see the **2201-00 Lika linear absolute sensor resolution** object and the **6501-00 Measuring step** object), please check that the **Scaling function** parameter is disabled (the bit 2 in the **6000-00 Operating parameters** object = 0; see on page 77);
- otherwise, if you need a custom resolution, enable the **Scaling function** parameter (the bit 2 in the **6000-00 Operating parameters** register = 1; see on page 77) and then set the resolution you need for your application next to the **6005-01 Position step setting** object (see on page 85);
- now, you can set a custom measuring range next to the the **6001-00 Total measuring range** and **6002-00 Total measuring range** objects (see on page 79);
- if you need you can enter the Preset value next to the **6003-00 Preset** object and then set it in the desired position; see on page 82;

- save the new setting values (use the **1010-01 Store parameters** object; see on page 68).

**NOTE**

Please consider that if the **Bypass** parameter (see on page 75) is set to "0" = disabled, the position value read by the encoder can be processed according to needs, so the user can scale the value, set a preset, and change the counting direction. On the contrary, if the **Bypass** parameter (see on page 75) is set to "1" = enabled, the information from the encoder is transmitted "as it is" and not processed in any way. The preset, scaling and counting direction functions -even if set and enabled- are ignored; also the output code setting is ignored. If, for example, the user sets a preset while the bypass mode is enabled, the value is accepted, but not activated. As soon as the bypass mode is disabled, the preset, scaling and counting direction functions -if set and enabled- become active and the position value will be accordingly.

**EXAMPLE**

We need to connect an **SMA5-GA-50** linear encoder.

The main features of the linear encoder are:

Resolution: **0.05 mm** (-50-, see the order code in the product datasheet).

Max. measuring length: **5,050 mm** (see the "Mechanical Specifications" in the product datasheet).

Output code: **Gray code** (-GA-, see the order code in the product datasheet).

SSI protocol: **25-bit "LSB Right Aligned" protocol** (see the User's manual).

2200-00 Lika linear absolute sensor setting

No of SSI clocks = 19h (= 25 dec)

Max No of Information = 11h (= Max. measuring length/Resolution = $5,050/0.05 = 101,000 \approx 2^{17} = 17$ bits)

SSI output code = 1h (= Gray code)

SSI protocol = 0h (= 25-bit "LSB Right Aligned" protocol)

2201-00 Lika linear absolute sensor resolution = 0032h (0.05 mm resolution = 50 μ m resolution)

6001-00 Total measuring range / 6002-00 Total measuring range = 0002 0000h (= $5,050/0.05 = 101,000$ information; default and max. value $2^{17} = 131,072$ dec = 0002 0000h) as a default;

If you want to use the physical resolution:

Scaling function in the **6000-00 Operating parameters** object = 0


If you need a custom resolution:

Scaling function in the **6000-00 Operating parameters** object = 1

6005-01 Position step setting \geq **2201-00 Lika linear absolute sensor resolution**

6001-00 Total measuring range / 6002-00 Total measuring range \leq 0002 0000h (= 5,050/0.05 = 101,000 information; max. value $2^{17} = 131,072$ dec = 0002 0000h); the user can set a custom measuring range

If you set a 0 preset along the path, when the encoder moves back and cross the zero, the value immediately after 0 will be $2^{\text{Max No of Information}-1}$, i.e. 131,071 (assuming that **6001-00 Total measuring range / 6002-00 Total measuring range** = 131,072).



EXAMPLE

We need to connect an **SMAX-BG-100** linear encoder.

The main features of the linear encoder are:

Resolution: **0.1 mm** (-100-, see the order code in the product datasheet).

Max. measuring length: **600 mm** (see the "Mechanical Specifications" in the product datasheet).

Output code: **Binary code** (-BG-, see the order code in the product datasheet).

SSI protocol: **13-bit "MSB Left Aligned" protocol** (see the User's manual).

2200-00 Lika linear absolute sensor setting

No of SSI clocks = 0Dh (= 13 dec), according to **Max No of Information**

Max No of Information = 0Dh (= Max. measuring length/Resolution = 600/0.1 = 6,000 \approx $2^{13} = 13$ bits)

SSI output code = 0h (= Binary code)

SSI protocol = 1h (= "MSB Left Aligned" protocol)

2201-00 Lika linear absolute sensor resolution = 0064h (0.1 mm resolution = 100 μ m resolution)

6001-00 Total measuring range / 6002-00 Total measuring range = 0000 2000h (= 600/0.1 = 6,000 information; default and max. value $2^{13} = 8,192$ dec = 0000 2000h) as a default;

If you want to use the physical resolution:

Scaling function in the **6000-00 Operating parameters** object = 0


If you need a custom resolution:

Scaling function in the **6000-00 Operating parameters** object = 1

6005-01 Position step setting = \geq **2201-00 Lika linear absolute sensor resolution**

6001-00 Total measuring range / 6002-00 Total measuring range \leq 0000 2000h (= 600/0.1 = 6,000 information; max. value $2^{13} = 8,192$ dec = 0000 2000h); the user can set a custom measuring range

If you set a 0 preset along the path, when the encoder moves back and cross the zero, the value immediately after 0 will be $2^{\text{Max No of Information}} - 1$, i.e. 8,191 (assuming that **6001-00 Total measuring range / 6002-00 Total measuring range** = 8,192).



6 – Quick reference with TwinCAT

Lika gateways for encoders are Slave devices and support "CANopen over EtherCAT" (CoE) mode for data transfer. In particular, they support the "CANopen DS301 Communication profile".

For any omitted specification on CANopen® protocol, please refer to "CiA Draft Standard Proposal 301. Application Layer and Communication Profile" and "CiA Draft Standard 406. Device profile for encoders" documents available at the address www.can-cia.org.

For any omitted specification on EtherCAT® protocol, please refer to "ETG.1000 EtherCAT Specification" documents available at the address www.ethercat.org.

6.1 System configuration using TwinCAT software system from Beckhoff


6.1.1 Setting the Network Card

Launch **TwinCAT System Manager**.


In the pane of the main window extend the devices tree and select the **I/O Devices** item; right-click the **I/O Devices** item and then press the **Append Device...** command.



In the **Insert Device** window select **EtherCAT** and then the **EtherCAT (Direct Mode)** item and confirm pressing the **OK** button.




If a network card has already been installed properly, the following window will appear and show the list of the installed devices.



Select the network card you want to use and then confirm the choice by pressing the **OK** button.

If there are no network cards installed, you must install one before proceeding. To do this, on the menu bar of the **TwinCAT System Manager** main window, select the **Options** menu and then press the **Show Real Time Ethernet Compatible Devices...** command.


The **Installation of TwinCAT RT – Ethernet Adapters** window will appear.




Now select the **Compatible Devices** item and choose the network card you want to install; finally press the **Install** button to confirm your choice.

6.1.2 Add new I/O modules (Boxes)

If one or more devices are connected to the network and switched ON, right-click the **Device 1 (EtherCAT)** item in the left pane of the **TwinCAT System Manager** main window and press the **Scan Boxes...** command.




At the end of the process some information will be listed in the right page as shown in the Figure here below.




If the devices are not already connected to the network it is necessary to use the XML file supplied with the converter: **Lika_IF55-xxx-EC_Vx.xml** (see at www.lika.biz).

Please note that the rotary encoder converters and the linear encoder converters use the same XML file, but you need to install the dedicated module.


If you want to know the firmware version of the device, press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item in the left pane of the **TwinCAT System Manager** main window: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **CoE - Online** page and refer to the **1009-00 Hardware version** and **100A-00 Software version** indexes.



Right-click the **Device 1 (EtherCAT)** item in the left pane of the **TwinCAT System Manager** main window and press the **Append Box...** command.



The **Insert EtherCAT Device** window will appear.



In the **Insert EtherCAT Device** window that appears select **Lika Electronic srl** and then **EtherCAT Converter** items; now choose from the list the encoder you want to install:


- Lika IF55-ROT-EC: IF55 gateway for SSI rotary encoders;
- Lika IF55-LIN-EC: IF55 gateway for SSI linear encoders.

Press the **OK** button to confirm your choice.

6.2 Setting the communication mode

6.2.1 Synchronous with SM3

In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Encoder or Lika IF55 Linear Encoder)** item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter **DC** page. Select the **Synchronous with SM3 (Inputs)** option in the **Operation Mode** box.




For any further information on the Synchronous with SM3 operation mode please refer to the "Synchronous with SM3" section on page 59 and to the [1C33 Sync Manager input parameter](#) object on page 71.

6.2.2 Synchronous with DC (SYNCO)

In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter **DC** page.

Select the **Synchronous with DC (SYNCO)** option in the **Operation Mode** box. Then press the **Advanced Settings...** button. The **Advanced Settings** window will appear.




In the section tabbed **SYNC 0** set the cycle time next to the **Sync Unit Cycle** box; sync time is calculated as multiple (or sub-multiple) of the value set in the **Sync Unit Cycle (µs)** item right above.


For any further information on the Synchronous with DC operation mode please refer to the "Synchronous with DC SYNCO" section on page 59 and to the **1C33 Sync Manager input parameter** object on page 71.

6.3 Process Data Objects

In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item. Expand the box to see Process Data Outputs (PDO). Some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **Process Data** page. In this page process data objects (TxPDO Mapping) are shown.




Process data objects can be displayed also by pressing the **TxPDO Mapping** item in the left pane of the **TwinCAT System Manager** main window; data is listed in the right pane.




6.4 COE Object Dictionary

In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **CoE - Online** page. In this page the objects dictionary is shown. This is the offline version of the object dictionary as read from the XML file.




Objects can also be read directly from the encoder; to do this click the **Advanced...** button: the **Advanced Settings** window will appear.



Select the **Dictionary** item in the left pane and then choose the **Online - via SDO Information** option in the **Dictionary** page; press the **OK** button to confirm.

6.5 Online Data

In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **Online** page to check the state of the encoder.



To display the encoder process data in real time, click the **Safe-OP** button if you want to display inputs only; click the **OP** button if you want to display both inputs and outputs.



WARNING

The structure of Data Objects (PDO and SDO) requires bytes to be sent from the Least Significant Byte (LSB) to the Most Significant Byte (MSB).

On the contrary in TwinCAT you must write and read data from MSB to LSB.

Furthermore in TwinCAT also strings must be entered in the reverse order:

- read default values: Data byte = 64 61 6F 6Chex = "daol" in ASCII code (means "load" if read in reverse);
- save parameters: Data byte = 65 76 61 73hex = "evas" in ASCII code (means "save" if read in reverse).

6.6 EEPROM upgrade



WARNING

The EEPROM upgrade process has to be accomplished by skilled and competent personnel. If the upgrade is not performed according to the instructions provided or a wrong or incompatible EEPROM program is installed then the unit may not be updated correctly, in some cases preventing the unit from working.



WARNING


The XML file version, the firmware version and the EEPROM version must always comply. For example: if the firmware version is H1_S2 (Hardware version: 1; Software version: 2), it is mandatory that the EEPROM version is S2, therefore you must then install the XML file version V2.




WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEPROM and XML file. So when you need to replace an old device installed in your network, then you must either upgrade all the devices in the network to the last version compatible with the new device; or you must downgrade the new device to the older version compatible with the devices already installed in the network.


1. In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item of the converter you need to update: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **EtherCAT** page.



2. Press the **Advanced Settings...** button; the **Advanced Settings** page will appear; in the directory tree on the left expand the **ESC Access** directory, then expand the **E²PROM** directory, finally select the **HEX Editor** item.




3. Press the **Read from File...** button and select the .BIN file provided by Lika Electronic to upgrade the EEPROM; please make sure you select the file suitable for the model you need to upgrade (for example: if you need to upgrade a linear encoder converter then you must select the **IF55-LIN-EC_eeprom_Hx_Sy.bin** file); finally press the **Open** button.



NOTE


In the .BIN file Hx is the hardware version of the converter, while Sy is the software version.

4. Move back to the previous **Advanced Settings** page and press the **Download** button. Now wait until the EEPROM writing process is carried out. The progress bar below in the page displays the progress of the operation. As soon as the process is completed press the **OK** button.




5. Now turn the power off, then on again.


- In the left pane of the **TwinCAT System Manager** main window delete all the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** items in the list. Select each box and then press the **DEL** key in the PC keyboard. Press **OK** to confirm.



- In the left pane of the **TwinCAT System Manager** main window select and right-click the **Device 1 (EtherCAT)** item; press the **Scan Boxes...** command in the menu.



- At the end of the scanning process all the devices available in the network are listed as shown in the Figure here below.



6.7 Firmware upgrade



WARNING

The firmware upgrade process has to be accomplished by skilled and competent personnel. If the upgrade is not performed according to the instructions provided or a wrong or incompatible firmware program is installed, then the unit may not be updated correctly, in some cases preventing the unit from operating.



WARNING

The XML file version, the firmware version and the EEPROM version must always comply. For example: if the firmware version is H1_S2 (Hardware version: 1; Software version: 2), it is mandatory that the EEPROM version is S2, therefore you must then install the XML file version V2.



WARNING

It is mandatory that in an EtherCAT network all devices are provided with the same version of the firmware, EEPROM and XML file. So when you need to replace an old device installed in your network, then you must either upgrade all the devices in the network to the last version compatible with the new device; or you must downgrade the new device to the older version compatible with the devices already installed in the network.

The firmware is a software program which controls the functions and operation of a device; the firmware program, sometimes referred to as "user program", is stored in the flash memory integrated inside the unit. Lika converters are designed so that the firmware can be easily updated by the user himself. This allows Lika Electronic to make new improved firmware programs available during the lifetime of the product.

Typical reasons for the release of new firmware programs are the necessity to make corrections, improve and even add new functionalities to the device.


The firmware upgrading program consists of a single file having .EFW extension. It is released by Lika Electronic Technical Assistance & After Sale Service.




WARNING

You must upgrade the EEPROM before upgrading the firmware.


1. In the left pane of the **TwinCAT System Manager** main window press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item of the converter you need to update: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **Online** page.



2. Press the **Bootstrap** button in the **State Machine** box; in the **BOOT** state the converter is ready to accept the firmware upgrade download process (the **BOOT** message appears next to the **Current State** item in the same box).




- Now press the **Download...** button in the **File Access Over EtherCAT** box; in the **Open** window that appears select the .EFW file provided by Lika Electronic to upgrade the firmware; please make sure you select the exact file of the model you need to upgrade (for example: if you have to upgrade a linear encoder converter then you must select the file **ECATFW_IF55-LIN-EC_Hx_Sy.efw**); finally press the **Open** button.




NOTE

In the .EFW file Hx is the hardware version of the converter, while Sy is the software version.

- In the **Edit FoE Name** page that appears on the screen enter the password 0x00000000 next to the **Password (hex)** item below in the page and then press the **OK** button to confirm. Now wait until the firmware file saving process is carried out. The progress bar below in the page displays the progress of the operation.



- To check whether the firmware upgrade procedure has been completed successfully enter the **Online** page in the **TwinCAT System Manager** main window and press the **Pre-Op** button in the **State Machine** box; if everything is ok, the converter enters the **PREOPERATIONAL** state (the **PREOP** message appears next to the **Current State** item in the same box).



7 - EtherCAT® interface


7.1 Basic Information on EtherCAT® Protocol

The EtherCAT protocol is designed to use the standard Ethernet dataframes for issuing data; in addition, and as regards the hardware, it is not necessary to install dedicated Masters for establishing and managing the EtherCAT communication because standard Ethernet network cards can be used. This results in a great advantage in terms of lower costs and simplicity of use because Ethernet network cards are used in standard personal computers and are easily commercially available.

An EtherCAT bus can be viewed as a single and large Ethernet device that receives and sends Ethernet telegrams; it can be considered an Ethernet subnet supported by an Ethernet dataframes structure.

However this "subnet" must be fitted with one only EtherCAT Master controller and several EtherCAT Slaves, but no Ethernet controller with downstream microprocessor must be present.

Here follows an Ethernet frame structure with EtherCAT:



Inside the Ethernet frames, data is transmitted among Master and Slaves using PDO (Process Data Objects) protocol. Each PDO message has inside one or more addresses for issuing data to the Slaves; data + address/es (and additional elements such as a validation checksum) joined together form an EtherCAT telegram (Datagram).


An EtherCAT frame can contain several telegrams and a complete control cycle often requires more than one frame.

7.1.1 Data transfer

Usually, in a data bus system, Master controller sends online a data request and then waits for data to be processed and sent back from each Slave node; this does not comply with a real-time system because the Master receives data from the Slaves in different moments and the whole system cannot be synchronized. In EtherCAT the real-time characteristic of the system is quite improved because data are processed "on-the-fly", using one single frame to acquire all data from all Slaves.

In fact the frame sent by the Master is read by each Slave node the data is addressed to while the telegram passes through the device; similarly, input data is inserted while the telegram passes through. Then the telegram is forwarded to the next device. Telegrams are only delayed by a few nanoseconds.


The last Slave issues back the complete frame to the Master with all the requested data (again passing through all the Slaves).



This efficient data flow is guaranteed by the 100BASE-TX full-duplex structure of EtherCAT bus which is fitted with two separated lines for transmitting and receiving data.

Moreover the protocols exchange takes place inside the hardware and it is thus independent from the CPU and the software processing.

7.1.2 ISO/OSI Layer model




* "Empty" means that the layer behaviour exists, but is not shown explicitly.

7.1.3 Topology


Several topologies of connection are supported by the EtherCAT networks: line, tree, daisy-chain, star, ...). EtherCAT networks can be configured in almost any topology in the same structure. The maximum length of the cable between two Slaves is 100 m / 328 ft; standard EtherCAT cables commercially available can be used.

The choice of the topology depends on the structural characteristics of the plant and it is made in order to reduce the complexity and time for cabling. Inside an EtherCAT network can be connected up to 65,535 devices. Some topology examples are shown in the Figures below:


LINE topology:



TREE topology:



DAISY CHAIN with drop lines topology:




7.1.4 Line Termination

The EtherCAT network needs no line termination because the line is terminated automatically; in fact every Slave is able to detect the presence of downstream Slaves.

An EtherCAT Slave is able to detect the presence of the signal in the outgoing line (Port 0) or in the return line (Port 1).

If the Slave is not able to detect the signal in its return line then it closes the communication ring by short-circuiting the TX signal of its outgoing line with the RX signal of its return line; in this way a telegram received through the outgoing line is processed and sent back through the TX of the return line.

The Slave sends a "carrier signal" or a telegram on TX of the outgoing line continuously and, once the next Slave is connected again, a signal on RX of the return line is detected again; so the short circuit is removed and the telegrams are sent on TX of the outgoing line.



7.1.5 Addressing

It is not necessary to assign a physical address to the device (for instance using a dip-switch) because the addressing of the Slave is automatic at power on during the initial scanning of the hardware configuration.

8 Bit	8 Bit	32 Bit		11 Bit	2	1	1	1	16 Bit
Cmd	Idx	Address		Len	R	C	R	M	IRQ
APxx		16 Bit	16 Bit						← Auto Increment Addressing (Position addressing)
FPxx		Address	Offset						← Fixed Physical Addressing (Node addressing)
Lxx		Logical Address							← Logical Addressing

The field for addressing is 32-bit long; there are three kinds of addressing:

- Auto Increment Addressing = Position Addressing: 16 bits indicate the physical position of the Slave inside the network while 16 bits are scheduled for local memory addressing; when the Slave receives the frame then it increments the position address and the Slave receiving the address 0 is the addressed device;
- Fixed Addressing = 16 bits indicate the physical address of the Slave inside the network while 16 bits are scheduled for addressing the local memory;
- Logical Addressing = the Slave is not provided with its own individual address, but it can read and write data in a section of the total memory space available (4 Gigabytes).

7.1.6 Communication mode

Lika converters with EtherCAT interface support the following operating modes:


- FreeRun: asynchronous mode;
- SM3 event: synchronous mode;
- DC: distributed clock synchronization mode (synchronous mode).

For a system that requires high performances in real time (closed-loop applications) we suggest using DC mode; if real time requirements are not so mandatory SM3 or Freerun modes can be used instead.


A reference parameter is the "Jitter": it represents the temporal fluctuation of the instant data sampling; in other words data sampled by the micro-controller is available in ECAT DPRAM memory after a certain time and the measure of the variability over time is the "jitter".

FreeRun

Asynchronous mode; the encoder position is sampled directly from EtherCAT frame sent by the Master; the position update is performed by an internal timer of the controller every 100 microseconds.



This operating mode has a high sampling jitter (up to 100 microseconds) and can be chosen only when cycle times are quite longer than the jitter if we want to ensure a sufficient real-time system performance.




Description	Min	Typ	Max	
Jitter	0		100	µsec
Cycle Time	1000		64000	µsec

See the [1C33 Sync Manager input parameter](#) entry on page 71.

Synchronous with SM3

In this mode data is sampled and then copied into the Sync Manager buffer as soon as previous data was read from the Master (SM event); in this way new sampled data is synchronous with the Master readings.



New data will be read by the Master at the next cycle (following SM3 event), so if the cycle time is too long, data could be relatively old for a real-time system. The main advantage is that data is updated exactly when the Master is reading (synchronous mode).


Description	Min	Typ	Max	
Jitter	0		7.2	ns
Cycle Time	62.5		64000	µs

See the [1C33 Sync Manager input parameter](#) entry on page 71.

Synchronous with DC SYNC0

In this operating mode data is sampled and then copied into the Sync Manager buffer simultaneously at SYNC0 event generated by the ESC capture/compare unit.


Time required for accomplishing these operations is set in the [1C33 Sync Manager input parameter](#) object; in particular in the **03 Shift Time** entry (1C33hex, sub3) and in the **06 Calc and Copy time** entry (1C33hex, sub6).



In this operating mode "Jitter" is a fundamental parameter in the sampling of two consecutive data. The main advantage of this mode is that there is a direct relation between the sampling instant and the absolute time of the system; in this way, if we know the shift times of the Slaves, we can have an exact image of the system at a given moment (with a tolerance equal to the jitter).

Description	Min	Typ	Max	
Jitter	0	100	200	µsec
Cycle Time	62.5		64000	µsec

7.1.7 EtherCAT State Machine (ESM)



EtherCAT Slave is a state machine; the communication and the operating characteristics depend on the current state of the device:

- **INIT**: it is the default state after power-on; in this state there is not direct communication between the Master and the Slave on the Application Layer; some configuration registers are initialized and the Sync Managers are configured.
- **PRE-OPERATIONAL** (PREOP): in this state the mailbox is active; both the Master and the Slave can use the mailbox and its protocols for exchanging specific initialization parameters of the application. Exchange of Process Data (PDO) is forbidden.
- **SAFE-OPERATIONAL** (SAFEOP): in this state the Master and the Slave can issue only input process data, while the output process data is still in the **SAFE-OPERATIONAL** state.
- **OPERATIONAL** (OP): in this state the Master and the Slave are enabled to send both input process data and output process data.
- **BOOTSTRAP** (BOOT): no process data communication. Communication only via mailbox on Application Layer available. Special mailbox configuration is


possible, e.g. larger mailbox size. In this state usually the FoE protocol is used for firmware download.

The current state of the Slave is signalled through the green **RUN** LED, see on page 26.

7.1.8 Slave configuration

The configuration of the Slave communication characteristics (Sync Manager configuration, addresses, synchronization modes, PDO mapping, ...) can be made both by using the XML file (EtherCAT Slave Information - ESI) and by loading data directly from the EEPROM (Slave Information Interface SII).

EEPROM content (SII):



7.1.9 Timing and Synchronization

The main feature of EtherCAT is its almost ideal representation of a real-time system.

Hence the Master has to synchronize all the Slaves at the same time in order to build a system where all nodes have the same reference time; this goal can be achieved by using "distributed clocks".

The Master downloads its clock into one of the slaves (customarily the first Slave) which becomes the reference clock for all the Slaves in the network; so it has the task of synchronizing the other Slaves. The Master controller periodically sends a special synchronization-telegram where the reference Slave writes its own "current time". This telegram is then sent to all the other Slaves that, in this way, provide for a new re-synchronization of their own clock in order to avoid possible drifts.

The synchronization of the reference time is very important in order to have an up-to-date "snapshot" of the system and accordingly take simultaneous actions in high sensitive applications such as the coordination in axis control operations. Besides, the EtherCAT Slave Controller (ESC) is fitted with a capture/compare unit that provides accurate synchronization signals (SYNCO or interrupts): they

are sent to the local micro-controller so that it is able to synchronize its own clock to the Slaves clock.

Sync Manager

Sync Manager has the task of synchronizing data transfer between the Master and the Slave and prevents the same memory area from being written by different events.

There are two synchronization modes:

- 3-Buffer Mode;
- 1-Buffer Mode.

Synchronisation mode is initialized through the XML file or by loading data directly from the EEPROM (SII).

Buffered Mode (3-Buffer Mode)

In this mode new data can be accessed at any time by both the EtherCAT Master and the ESC controllers; no timing restrictions are imposed.

Three buffers are necessary (three consecutive memory areas); one buffer is always available to the ESC controller for writing and one buffer always contains updated data to be read by the Master.

Customarily this mode is used for cyclic data exchange, i.e. process data communication.

Mailbox Mode (1-Buffer Mode)

In this mode a "handshake" between the Master and the Slave must be used; in fact one only memory buffer is available to both the Master and the Slave for writing and reading; the Master (or the Slave) is enabled to write only when the buffer is empty, that is when the Slave (or the Master) has finished reading the data buffer. And vice versa: the Master (or the Slave) is enabled to read only when the buffer is empty, that is when the Slave (or the Master) has finished writing the data buffer. The mailbox mode is typically used for application layer protocols and exchange of acyclic data (e.g. parameter settings).

The converter features four Sync Managers, see the [1C00 Sync Manager Communication Type](#) object on page 70:

- **Sync Manager 0 (SM MailBox Receive, SM0)**
Used for mailbox write transfers (Master to Slave).
The module has a configurable write mailbox size with default size of 276 bytes, corresponding to 255 bytes plus relevant protocol headers and padding.
- **Sync Manager 1 (SM MailBox Send, SM1)**
Used for mailbox read transfers (Slave to Master).
The module has a configurable read mailbox size with default size of 276 bytes, corresponding to 255 bytes plus relevant protocol headers and padding.
- **Sync Manager 2 (SM PDO output, SM2)**
It contains the RxPDOs (i.e., Sync Manager 2 holds the Read Process Data).

- **Sync Manager 3 (SM PDO input, SM3)**
It contains the TxPDOs (i.e., Sync Manager 3 holds the Write Process Data).

7.2 CANopen Over EtherCAT (CoE)

Lika converters for encoders are Slave devices and support the "CANopen Over EtherCAT" (CoE) mode for data transfer. In particular, they support the "CANopen DS301 Communication profile", Class 2.

For any omitted specification on CANopen® protocol, please refer to the "CiA Draft Standard Proposal 301. Application Layer and Communication Profile" and the "CiA Draft Standard 406. Device profile for encoders" documents available at the address www.can-cia.org.

For any omitted specification on the EtherCAT® protocol, please refer to the "ETG.1000 EtherCAT Specification" document available at the address www.ethercat.org.

7.2.1 XML file


EtherCAT® converters for linear encoders are supplied with their own XML file **Lika_IF55-xxx-EC_Vx.xml** (see at www.lika.biz).

Please note that the rotary encoder converters and the linear encoder converters use the same XML file, but you need to install the dedicated module.

For any information on the firmware upgrade procedure refer to the section "6.7 Firmware upgrade" on page 49. For any information on the EEPROM upgrade procedure refer to the section "6.6 EEPROM upgrade" on page 44).

The XML file has to be installed on the EtherCAT® Master device.

If you want to know the firmware version of a device, press the **Box (Lika IF55 Rotary Converter or Lika IF55 Linear Converter)** item in the left pane of the **TwinCAT System Manager** main window: some tabbed pages for configuring and managing the device will appear in the right pane. Enter the **CoE - Online** page and refer to the **1009-00 Hardware version** and **100A-00 Software version** objects.



7.2.2 Communication messages

EtherCAT Datagram of CoE mode has the following structure:

Mbx Header	CoE Cmd			Cmd specific data
type = 3	Number	res	Type	
6 bytes	9 bits	3 bits	3 bits	0 ... 1478 bytes

Mbx Header = 3 CoE mode

Number = 0 in case of SDO messages
 ≠ 0 in case of PDO messages, it defines the type of service reserved bits

Type = 0 reserved
 = 1 Emergency message
 = 2 SDO request
 = 3 SDO response
 = 4 Transmitted PDO (TxPDO)
 = 5 Received PDO (RxPDO)
 = 6 Remote transmission request of TxPDO
 = 7 Remote transmission request of RxPDO
 = 8 SDO information
 = 9 ... 15 reserved

Cmd specific data PDO messages: are the process data, e.g. position value
 SDO messages: standard CANopen frame

Transmit (tx) or receive (rx) "Type" is viewed from the Slave side.

7.2.3 Process Data Objects (PDO)

PDO messages are used for transmitting or receiving process data in real time; data to be transmitted or received is defined in PDO Mapping and managed by Sync Manager PDO Mapping.

7.2.4 Service Data Objects (SDO)

SDO messages are issued via Mailbox (low priority data); Segmented SDO Service and SDO Complete Access are not supported (transfer of low size data and one sub-index at a time).

"CoE Cmd type" = 2 or 3

Structure of "Cmd specific data":

Cmd specific data				
SDO control	Index	Sub index	Data	Data optional
8 bits	16 bits	8 bits	32 bits	1 ... 1470 bytes

SDO control	standard CANopen SDO Service
Index	parameter index
Sub index	parameter sub-index
Data	parameter value
Data optional	optionally, more than 4 bytes of data can be sent in one frame. Full mailbox size usable.

Index and sub-index values are described in the "Object dictionary".

7.2.5 Object dictionary

The most important part of a device profile is the Object Dictionary. The Object Dictionary is essentially a grouping of objects accessible via the network in an ordered, pre-defined mode. Each object within the dictionary is addressed using a 16-bit index.

The Object Dictionary can contain a maximum of 65,536 entries.

The user-related objects are grouped in three main areas: the Communication Profile Area, the Manufacturer Specific Profile Area and the Standardised Device Profile Area. The objects are all described in the XML file.

The **Communication Profile Area** at indexes from 1000h to 1FFFh contains the communication specific parameters for the EtherCAT network. These entries are common to all devices. PDO objects and SDO objects are described in this section. The Communication Profile Area objects comply with the "CiA Draft Standard Proposal 301. Application Layer and Communication Profile". Refer to the "Communication Profile Area objects (DS301)" section on page 68.

The **Manufacturer Specific Profile Area** at indexes from 2000h to 5FFFh is free to add manufacturer-specific functionality. Refer to the "Manufacturer Specific Profile Area objects" section on page 73.

The **Standardised Device Profile Area** at indexes from 6000h to 9FFFh contains all data objects common to a class of devices that can be read or written via the network. The device profiles may use entries from 6000h to 9FFFh to describe the device parameters and the device functionality. The Standardised Device Profile Area objects comply with the "CiA Draft Standard 406 CANopen Device profile for encoders". Refer to the "Standardised Profile Area objects (DS406)" section on page 77.

In the following pages the objects implemented are listed and described as follows:

Index-subindex Object name

[data types, attribute]

- Index and sub-index are expressed in hexadecimal notation.
- Attribute:
 ro = read only access
 rw = read and write access

Signed8 / Unsigned8 data type:

Process data bytes							
byte 4							
7	6	5	4	3	2	1	0
MSbit		...				LSbit	

Signed16 / Unsigned16 data type:

Process data bytes	
byte 4	byte 5
LSByte	MSByte

Signed32 / Unsigned32 data type:

Process data bytes			
byte 4	byte 5	byte 6	byte 7
LSByte	MSByte



NOTE

Always save the new values after setting in order to store them in the non-volatile memory permanently. Use the **1010-01 Store parameters** object, see on page 68.

Should the power supply be turned off all data that has not been saved previously will be lost!

Communication Profile Area objects (DS301)

1000-00 Device type

[Unsigned32, ro]

It contains information about the device type. The object describes the type of device and its functionality.

Default = 0000 0000h = generic device

1008-00 Device Name

[String, ro]

It shows the manufacturer device name, expressed in hexadecimal ASCII code.

Default = 494635352D524F542D4543 = "IF55-ROT-EC" = IF55 converter with EtherCAT interface for SSI rotary encoders
 494635352D4C494E2D4543 = "IF55-LIN-EC" = IF55 converter with EtherCAT interface for SSI linear encoders

1009-00 Hardware version

[String, ro]

It shows the hardware version of the device, expressed in hexadecimal ASCII code.

E.g.: 483031 = H01 = Hardware version 01.

100A-00 Software version

[String, ro]

It shows the software version of the device, expressed in hexadecimal ASCII code.

E.g.: 533031 = S01 = Software version 01.

1010-01 Store parameters

[Unsigned32, rw]

Use this object to save all parameters on the non-volatile memory.

Write "save" in hexadecimal ASCII code in the data bytes:

Master → Encoder

Cmd specific data							
Cmd	Index		Sub	Data			
23	10	10	01	73	61	76	65
				s	a	v	e

Encoder → Master (confirmation)

Cmd specific data							
Cmd	Index		Sub	Data			
60	10	10	01	00	00	00	00

1011-01 Restore default parameters

[Unsigned32, rw]

This object allows the operator to restore all parameters to default values. The default parameters are set at the factory by Lika Electronic engineers to allow the operator to run the device for standard operation in a safe mode. A list of machine data and the relevant default parameters preset by Lika Electronic engineers is available on page 94.

Write "**load**" in hexadecimal ASCII code in the data bytes:

Master → Encoder

Cmd specific data							
Cmd	Index		Sub	Data			
23	11	10	01	6C	6F	61	64
				l	o	a	d

Encoder → Master (confirmation)

Cmd specific data							
Cmd	Index		Sub	Data			
60	11	10	01	00	00	00	00



NOTE

To save the default values execute the "Store parameters" function (see the **1010-01 Store parameters** object). When the power is turned off, parameters not saved are lost.

1018 Identity

[Unsigned8, ro]

This object contains general information about the device. Sub-index 00 contains the number of entries.

Default = 4

01 Vendor ID

[Unsigned32, ro]

It provides the manufacturer-specific vendor ID. The EtherCAT vendor ID is equal to the CANopen vendor ID.

Default = 0000 012Eh

02 Product code

[Unsigned32, ro]

The manufacturer-specific product code identifies a specific device version.

Default = 0000 0009h

03 Revision

[Unsigned32, ro]

The manufacturer-specific revision number consists of a major revision number and a minor revision number. The major revision number identifies a specific device behaviour. The minor revision number identifies different versions with the same device behaviour.

Default = device dependent

7	...	0	15	...	8	23	...	16	31	...	24
Minor revision number						Major revision number					
LSB					MSB		

04 Serial number

[Unsigned32, ro]

It provides the Serial Number of the device. It is 0 if no serial number is provided.

Default = 0000 0000h

1A00-01 PDO mapping parameter

[Unsigned8, ro]

This object contains the mapping parameters for the PDOs the EtherCAT device is able to transmit. Sub-Index 00 contains the number of entries.

01 Mapped Object 001

[Unsigned32, rw]

Sub-Index 01 contains the information of the mapped application object 001. The object describes the content of the PDO by its index, sub-index and length.

The length contains the length of the application object in bits. This may be used to verify the mapping.

7	0	15	8	23	16	31	24
Length		Sub-Index		Index			
LSB				MSB			

Default = 6004 0020h = **6004-00 Position value** object, length 32 bits

1C00 Sync Manager Communication Type

[Unsigned8, ro]

This object contains the number and type of Sync Manager Communication Types supported by the converter. Sub-Index 00 specifies the number of Sync Manager channels. Refer also to the "Sync Manager" section on page 62.

01 SM MailBox Receive (SM0)

[Unsigned8, ro]

Used for mailbox write transfers (Master to Slave).

Default = 01h

02 SM MailBox Send (SM1)

[Unsigned8, ro]

Used for mailbox read transfers (Slave to Master).

Default = 02h

03 SM PDO output (SM2)

[Unsigned8, ro]

It contains the RxPDOs (i.e. Sync Manager 2 holds the Read Process Data).

Default = 03h

04 SM PDO input (SM3)

[Unsigned8, ro]

It contains the TxPDOs (i.e. Sync Manager 3 holds the Write Process Data).

Default = 04h

1C12-00 Sync Manager RxPDO Assigned

[Unsigned8, ro]

This object specifies whether the device uses Receive PDO messages. This device does not support Receive PDO messages.

Default = 00h

1C13-01 Sync Manager TxPDO Assigned

[Unsigned32, ro]

This object specifies whether the device uses Transmit PDO messages. Sub-Index 00 specifies the number of entries, i.e. the number of assigned TxPDOs.

01 Subindex 001

This device uses TxPDO messages to send the position value.

Default = 0000 1A00h = **1A00-01 PDO mapping parameter** object**1C33 Sync Manager input parameter****1C33 Sync Manager input parameter** object contains the input synchronization parameters. Some of them are calculated dynamically and depend on both the device configuration (programmed resolution, counting direction, ...) and the selected synchronization mode (SM or DC). Sub-Index 00 contains the number of entries.**01 Sync Type**

[Unsigned16, rw]

It allows to select the synchronization mode. For more information refer to page 58.

0: FreeRun: see on page 58;

1: Synchronous with SM3 Event: see on page 59;

2: DC mode synchronous with SYNC0 event: see on page 59.

Default = 1

02 Cycle time

[Unsigned32, ro]

This parameter depends on the **01 Sync Type** selected. Application cycle time, i.e. interval between two position samplings (internal timer). The value is expressed in nanoseconds (ns).

If 0 = "FreeRun": interval between two position samplings (internal timer).

If 1 = "Synchronous with SM3": minimum interval between two SM3 events.

If 2 = "DC mode synchronous with SYNC0 event": SYNC0 cycle time.

03 Shift Time

[Unsigned32, ro]

Interval between the synchronization event and the moment of inputs latching from hardware. This parameter is calculated dynamically and expressed in nanoseconds (ns).

04 Sync modes supported

[Unsigned16, ro]

It shows the list of the supported synchronization modes.

bit 0: FreeRun (supported)

bit 1: Synchronous with SM3 (supported)

bit 2: Synchronous with DC SYNC0 (supported)

Default = 7

05 Minimum cycle time

[Unsigned32, ro]

Min. duration of the device internal cycle time. This parameter is calculated dynamically and depends on the operating parameters and the position value. It is expressed in nanoseconds (ns).

06 Calc and Copy time

[Unsigned32, ro]

Time the internal micro-controller (DSP) needs to make calculations on latched optical reading of position and then copy updated data from local memory to ESC memory (Sync Manager) before they are available to EtherCAT. This parameter is calculated dynamically and depends on the operating parameters and the position value. It is expressed in nanoseconds (ns).



NOTE

Always save the new values after setting in order to store them in the non-volatile memory permanently. Use the **1010-01 Store parameters** object, see on page 68.

Should the power supply be turned off all data that has not been saved previously will be lost!

Manufacturer Specific Profile Area objects

2200-00 Lika linear absolute sensor setting

[Unsigned32, rw]

byte 4	byte 5	byte 6	byte 7		
Not used	No of SSI clocks	Max No of Information	bit 7	bits 4 ... 6	bits 0 ... 3
			Bypass	SSI output code	SSI protocol

Default = 0019 1310h

No of SSI clocks

It sets the number of SSI clocks required by the SSI encoder to send the complete data word. The number of clocks depends on the max. number of information and the type of SSI protocol. For any information on the SSI clocks required please refer to the "User's manual" of the connected encoder.

Default = 19h

Min. value = 01h

Max. value = 20h



EXAMPLE

We need to connect the following linear encoder: **SMA5-GA-50**. SMA5 encoder always requires 25 clocks (the length of the word is always 25 bits, regardless of the max. number of information to provide). Thus you have to set 19h in this entry. For further information refer to the encoder's "User's manual".



EXAMPLE

We need to connect the following linear encoder: **SMAX-BG-100**. The number of clocks depends on the max. number of information (see the example in the following parameter). Let's say the max. number of information is 6,000, thus it requires 13 clocks. You have to set 0Dh in this entry. For further information refer to the encoder's "User's manual".

Max No of Information

It sets the max. number of information (expressed in bits) the SSI encoder can output for the max. measuring length, i.e. the total physical resolution. The value depends on the encoder resolution and the max. measuring length. As soon as you confirm the value, the system automatically sets the default value of the **6001-00 Total measuring range** and **6002-00 Total measuring range** objects accordingly. For any information on the max. number of information please refer to the "User's manual" of the connected encoder.

Default = 13h

Min. value = 01h

Max. value = 1Eh

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-GA-50**. Its resolution is **0.05 mm** (see the order code).

The max. measuring length of the the SMA5 linear encoder on the MTA5 scale is **5,050 mm**.

The max. number of information the encoder can output results from the following calculation:

$$\text{Max. No of Information} = \frac{\text{Max. measuring range}}{\text{Resolution}}$$

$$\text{Max. No of Information} = \frac{5,050}{0.05} = \mathbf{101,000}$$

Now you have to "round up" the result to the next highest power of 2, that is: $131,072 = 2^{17}$. Thus the number of bits is "17". The value to set in this entry is 11h.

**EXAMPLE**

We need to connect the following linear encoder: **SMAX-BG-100**. Its resolution is **0.1 mm** (see the order code).

The max. measuring length of the SMAX linear encoder on the MTAX scale is **600 mm**.

The max. number of information the encoder can output results from the following calculation:

$$\text{Max. No of Information} = \frac{\text{Max. measuring range}}{\text{Resolution}}$$

$$\text{Max. No of Information} = \frac{600}{0.1} = \mathbf{6,000}$$

Now you have to "round up" the result to the next highest power of 2, that is: $8,192 = 2^{13}$. Thus the number of bits is "13". The value to set in this entry is 0Dh.

SSI protocol

It sets the SSI protocol used by the SSI encoder to arrange the absolute position information. The SSI protocol can be the 25-bit "LSB Right Aligned" protocol (0h) or the "MSB Left Aligned" protocol (1h). For any information on the SSI protocol please refer to the "User's manual" of the connected encoder.

Default = 0h

Min. value = 0h "LSB Right Aligned" protocol

Max. value = 1h "MSB Left Aligned" protocol

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-GA-50**.
SMA5 encoder uses the 25-bit "LSB Right Aligned" protocol to arrange the absolute position information. Thus you have to set the value 0h in this entry. For further information refer to the encoder's "User's manual".

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-BG-100**.
"BG" in the order code means that "MSB Left Aligned" protocol and Binary code are used to arrange the absolute position information. Thus you have to set the value 1h in this entry. For further information refer to the encoder's "User's manual".

SSI output code

It sets the output code used by the SSI encoder to output the absolute position information. The output code can be Binary (0h) or Gray (1h). For any information on the output code please refer to the "User's manual" of the connected encoder.

Default = 1h

Min. value = 0h

Max. value = 1h

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-GA-50**.
SMA5 encoder uses the Gray code to output the absolute position information. Thus you have to set the value 1h = Gray in this entry. For further information refer to the encoder's "User's manual".

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-BG-100**.
"BG" in the order code means that "MSB Left Aligned" protocol and Binary code are used to arrange the absolute position information. Thus you have to set the value 0h = Binary in this entry. For further information refer to the encoder's "User's manual".

Bypass

If the bit 7 **Bypass** = 0 = Bypass disabled, the "Bypass mode" is disabled, that is: the position value (refer to the object **6004-00 Position value** on page 83) read by the encoder can be processed according to needs, so the user can scale the value, set a preset and change the counting direction.

If **Bypass** = 1 = Bypass enabled, the "Bypass mode" is enabled, that is: the information from the encoder is transmitted "as it is" and not processed in any

way. The preset, scaling and counting direction functions -even if set and enabled- are ignored. If, for example, the user sets a preset while the "Bypass mode" is enabled, the value is accepted, but not activated. As soon as the "Bypass mode" is disabled, the preset, scaling and counting direction functions -if set and enabled- become active and the position value will be arranged accordingly.

Default = 0h

Min. value = 0h = Bypass disabled

Max. value = 1h = Bypass enabled

2201-00 Lika linear absolute sensor resolution

[Unsigned16, rw]

It sets the physical resolution of the linear encoder expressed in microns (μm). Usually the physical resolution can be read in the order code (see the product datasheet). As soon as the user confirms the value, the system automatically sets the default value of the **6005-01 Position step setting** and **6501-00 Measuring step** objects accordingly.

Default = 000Ah

Min. value = 0001h

Max. value = 1388h



EXAMPLE

We need to connect the following linear encoder: **SMA5-GA-50**.

As you can see in the product datasheet, "50" in the order code means 0.05 mm resolution = 50 μm resolution. Thus you have to set the value 0032h in this object. For further information refer also to the encoder's "User's manual".



EXAMPLE

We need to connect the following linear encoder: **SMA5-BG-100**.

As you can see in the product datasheet, "100" in the order code means 0.1 mm resolution = 100 μm resolution. Thus you have to set the value 0064h in this object. For further information refer also to the encoder's "User's manual".

Standardised Profile Area objects (DS406)

6000-00 Operating parameters

[Unsigned16, rw]

Bit	Function	bit = 0	bit = 1
0 and 1	not used		
2	Scaling function	Disabled	Enabled
3	Code sequence	Standard	Reversed
4 ... 15	not used		

Default values are highlighted in bold

Default = 0000h

Scaling function

This is meant to disable (0) / enable (1) the scaled parameters **6005-01 Position step setting**, **6001-00 Total measuring range** and **6002-00 Total measuring range**.

When this option is disabled (bit 2 = 0), the device uses the physical resolution and the max. number of physical information to arrange the absolute position information (see the **2201-00 Lika linear absolute sensor resolution** object and the **Max No of Information** entry; the **6005-01 Position step setting** and **6501-00 Measuring step** objects are automatically set accordingly); the **6005-01 Position step setting**, **6001-00 Total measuring range** and **6002-00 Total measuring range** objects cannot be programmed.

On the contrary, if it is enabled (bit 2 = 1), the user is allowed to enter the custom resolution in the **6005-01 Position step setting** object and the custom number of information in the **6001-00 Total measuring range** / **6002-00 Total measuring range** objects and these values are used to calculate the position information.

To know whether the **Scaling function** is currently enabled, you can read the bit 2 **Scaling** of the **6500-00 Operating status** object, see on page 88.

**WARNING**

When you enable the scaling function (**Scaling function** = 1), a counting error, i.e. a jump in the position count, may occur if the following conditions arise:

- a physical zero setting has been performed in the linear sensor;
- the **6005-01 Position step setting** object value is not a multiple of the physical resolution as set next to the **2201-00 Lika linear absolute sensor resolution** object;
- the measuring range (**6001-00 Total measuring range** and **6002-00 Total measuring range** objects) is not a power of 2 submultiple of the maximum measuring range.

If the above described conditions arise, a counting error may occur when the sensor crosses the physical zero point.

If the scaling function is disabled (**Scaling function** = 0), the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1) yet no physical zero setting has been performed in the linear sensor, the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1), the **6005-01 Position step setting** object value is a multiple of the physical resolution and the measuring range (**6001-00 Total measuring range** and **6002-00 Total measuring range** objects) is a power of 2 submultiple of the maximum measuring range, the transmitted position values are consistent, regardless of the physical zero setting.

**WARNING**

Every time you enable the scaling function and/or change the scaling values (see the **6001-00 Total measuring range**, **6002-00 Total measuring range** and **6005-01 Position step setting** objects) then you are required to set a new preset value (see the **6003-00 Preset** object) and finally save the new parameters (see the **1010-01 Store parameters** object).

**NOTE**

Please consider that if the **Bypass** parameter (see on page 75) is set to "1" = Bypass enabled, the scaling function -even if enabled- is ignored.

Code sequence

This is intended to set whether the count is increasing (count up information) when the linear encoder moves in the standard direction (it is indicated in the encoder's manual) or when the encoder moves in reverse of the standard direction. Setting 0 (bit 3 = 0) causes the encoder counting to increase when the encoder moves in the standard direction; setting 1 (bit 3 = 1) causes the encoder counting to increase when the encoder moves in reverse of the standard direction. For any information on the standard and inverted counting direction please refer to the specific manual of the encoder.

To know whether the **Code sequence** is currently enabled, you can read the bit 3 **Counting direction** in the **6500-00 Operating status** object, see on page 88.

**WARNING**

Every time you change the **Code sequence**, then you are required to set a new preset value (see the **6003-00 Preset** object) and finally save the new parameters (see the **1010-01 Store parameters** object).

6001-00 Total measuring range

[Unsigned32, rw]

**WARNING**

This register is active only if the bit 2 **Scaling function** in the **6000-00 Operating parameters** object is set to "1"; otherwise the user cannot enter any value in this object. As soon as the user confirms the value in the **Max No of Information** parameter, the program automatically sets the default value of the **6001-00 Total measuring range** and **6002-00 Total measuring range** objects accordingly.

Furthermore, if the **Bypass** parameter (see on page 75) is set to "1" = Bypass enabled, the scaling function -even if enabled- is ignored and the position information is outputted as it is.

If the **Scaling function** is disabled (the bit 2 in the **6000-00 Operating parameters** object is set to "0"), then **6001-00 Total measuring range / 6002-00 Total measuring range** = $2^{\text{Max No of Information}}$.

It sets the length of the travel the encoder has to measure. The value is expressed in number of information.

It can be either the number of information for the max. measuring length (for instance, if the application needs the whole path); or the number of information for just a part of the scale if the application only uses a section of the scale. Thus this value must be less than or equal to the number of information resulting from the scale max. measuring length ($2^{\text{Max No of Information}}$).

We suggest setting a value that is a power of 2 submultiple of the maximum measuring range (**Max No of Information**) not to cause a counting error, i.e. a jump in the position count when the sensor crosses the physical zero point (see the WARNING below).

Default = $2^{\text{Max No of Information}}$

Min. value = 0000 0002h


Max. value = $2^{\text{Max No of Information}}$

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-GA-50**.

As you can see in the product datasheet, "50" in the order code means a **0.05 mm** resolution. Let's say the mechanical travel of our application is the max. measuring length the SMA5 linear encoder is allowed to run on the MTA5 scale, i.e. **5,050 mm**. Thus the max. number of information is **101,000 ≈ 17 bits** (for the complete explanation refer to the **Max No of Information** parameter). After having set the **Max No of Information** parameter, the system automatically sets the value 0002 0000h = 131,072 = 2^{17} in this register. If you need a custom measuring range, you need to enable the **Scaling function** and then set a value less than $2^{17} = 131,072$ here.

If you set a preset along the path, when the encoder moves back and cross the zero, the value immediately after 0 will be $2^{\text{Max No of Information}} - 1$, i.e. 131,071.




EXAMPLE

We need to connect the following linear encoder: **SMAX-BG-100**.

As you can see in the product datasheet, "100" in the order code means a **0.1 mm** resolution. Let's say the mechanical travel of our application is the max. measuring length the SMAX linear encoder is allowed to run on the MTAX scale, i.e. **600 mm**. Thus the max. number of information is **6,000 ≈ 13 bits** (for the complete explanation refer to the **Max No of Information** parameter). After having set the **Max No of Information** parameter, the system automatically sets the value 0000 2000h = 8,192 = 2¹³. If you need a custom measuring range, you need to enable the **Scaling function** and then set a value less than 2¹³ = 8,192 here.


If you set a preset along the path, when the encoder moves back and cross the zero, the value immediately after 0 will be 2^{Max No of Information} - 1, i.e. 8,191.



EXAMPLE

We need to connect a **SMA5-GA-50**, its physical resolution is **0.05 mm**. Let's say the mechanical travel of our application is **1000 mm**. Thus the max. number of information is **20,000 ≈ 15 bits** (for the complete explanation refer to the **Max No of Information** parameter). Thus you must enable the **Scaling function** parameter and set the value 0000 4E20h in this parameter (instead of the default value 0002 0000h).

In this way you will obtain several 20,000 information sections following each other all along the whole measuring length. The position information will be from 0 to 19,999; then again from 0 to 19,999 and so on.



← max measuring length →



WARNING

When you enable the scaling function (**Scaling function** = 1), a counting error, i.e. a jump in the position count, may occur if the following conditions arise:

- a physical zero setting has been performed in the linear sensor;
- the **6005-01 Position step setting** object value is not a multiple of the physical resolution as set next to the **2201-00 Lika linear absolute sensor resolution** object;

- the measuring range (**6001-00 Total measuring range** and **6002-00 Total measuring range** objects) is not a power of 2 submultiple of the maximum measuring range.

If the above described conditions arise, a counting error may occur when the sensor crosses the physical zero point.

If the scaling function is disabled (**Scaling function** = 0), the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1) yet no physical zero setting has been performed in the linear sensor, the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1), the **6005-01 Position step setting** object value is a multiple of the physical resolution and the measuring range (**6001-00 Total measuring range** and **6002-00 Total measuring range** objects) is a power of 2 submultiple of the maximum measuring range, the transmitted position values are consistent, regardless of the physical zero setting.



WARNING

When you change the value next to **6001-00 Total measuring range** or **6002-00 Total measuring range** objects, then you must check the value in the **6003-00 Preset** object and perform the preset operation.



NOTE

The **6001-00 Total measuring range** and **6002-00 Total measuring range** objects are exactly the same thing. When you change the value next to this **6001-00 Total measuring range** object you also change the value next to the **6002-00 Total measuring range** object; and vice versa.

6002-00 Total measuring range

[Unsigned32, rw]

This object is exactly the same as the **6001-00 Total measuring range** object. When you change the value next to this **6002-00 Total measuring range** object you also change the value next to the **6001-00 Total measuring range** object; and vice versa. For any information refer to the **6001-00 Total measuring range** object.

Default = $2^{\text{Max No of Information}}$

Min. value = 0000 0002h

Max. value = $2^{\text{Max No of Information}}$

6003-00 Preset

[Unsigned32, rw]

This object allows to set the encoder position to a Preset value. The Preset function is meant to assign a desired value to a physical position of the encoder. The chosen physical position will get the value set next to this object and all the previous and following positions will get a value according to it. This function is useful, for example, when the zero position of the encoder and the zero position of the axis need to match. The preset value will be set for the position of the encoder in the moment when the preset value is sent.

Default = 0000 0000h



EXAMPLE

Let's take a look at the following example to better understand the preset function and the meaning and use of the related objects and commands: **6003-00 Preset** and **6509-00 Offset**.

The encoder position which is transmitted results from the following calculation:

Transmitted value = read position (it does not matter whether the position is physical or scaled) + **6003-00 Preset** - **6509-00 Offset**.

If you never set the **6003-00 Preset** and you never performed the preset setting, then the transmitted value and the read position are necessarily the same as **6003-00 Preset** = 0 and **6509-00 Offset** = 0.

When you set the **6003-00 Preset** and then execute the preset setting, the system saves the current encoder position in the **6509-00 Offset** object. It follows that the transmitted value and the **6003-00 Preset** are the same as read position - **6509-00 Offset** = 0; in other words, the value set next to the **6003-00 Preset** object is paired with the current position of the encoder as you wish.

For example, let's assume that the value "50" is set next to the **6003-00 Preset** object and you execute the preset setting when the encoder position is "1000". In other words, you want to receive the value "50" when the encoder reaches the physical position "1000".

We will obtain the following information sequence:

Transmitted value = read position ("1000") + **6003-00 Preset** ("50") - **6509-00 Offset** ("1000") = 50.

The following transmitted value will be:

Transmitted value = read position ("1001") + **6003-00 Preset** ("50") - **6509-00 Offset** ("1000") = 51.

And so on.

To set the preset value you must send the following command:

Set the Preset value 6003-00 Preset (= 1000 = 3E8h)

Master → Encoder

Cmd specific data							
Cmd	Index		Sub	Data			
23	03	60	00	E8	03	00	00

Encoder → Master (Set confirmation)

Cmd specific data							
Cmd	Index		Sub	Data			
60	03	60	00	00	00	00	00



NOTE

- If the scaling function is disabled (see the bit 2 **Scaling function** in the **6000-00 Operating parameters** object = 0), then **6003-00 Preset** must be less than or equal to $2^{\text{Max No of Information}} - 1$ (for instance: **Max No of Information** = 13 bits; $2^{13} - 1 = 8,191$).
- If the scaling function is enabled (see the bit 2 **Scaling function** in the **6000-00 Operating parameters** object = 1), then **6003-00 Preset** must be less than or equal to **6001-00 Total measuring range** / **6002-00 Total measuring range**.



WARNING

Check the value in the **6003-00 Preset** object and perform the preset operation every time you change the value next to the **Code sequence** parameter or **6001-00 Total measuring range**, **6002-00 Total measuring range** and **6005-01 Position step setting** objects.



NOTE

Please consider that if the **Bypass** parameter (see on page 75) is set to "1" = Bypass enabled, the preset function -even if enabled and activated- is ignored.

6004-00 Position value

[Unsigned32, ro]

This object contains the current position value of the encoder.

The output value is scaled according to the scaling parameters (if the scaling function is enabled), see the bit 2 **Scaling function** of the **6000-00 Operating parameters** object and according to the setting in the **Bypass** parameter (see on page 75). The **6004-00 Position value** object is mapped in the **1A00-01 PDO mapping parameter** object, see on page 70.



NOTE

Please consider that if the **Bypass** parameter (see on page 75) is set to "0" = disabled, the position value read by the encoder can be processed according to needs, so the user can scale the value, set a preset and change the counting direction. On the contrary, if the **Bypass** parameter is set to "1" = enabled, the information from the encoder is transmitted "as it is" and not processed in any

way. The preset, scaling, and counting direction functions -even if set and enabled- as well as the output code are ignored. If, for example, the user sets a preset while the "Bypass mode" is enabled, the value is accepted, but not activated. As soon as the "Bypass mode" is disabled, the preset, scaling, and counting direction functions -if set and enabled- become active and the **6004-00 Position value** will be accordingly.

To convert the read position value into nanometres [nm] (and into micrometres or millimetres or any other engineering unit afterwards) you must multiply the read position by the value set next to the **6501-00 Measuring step** object (if the bit 2 **Scaling function** in the **6000-00 Operating parameters** object is disabled = 0); otherwise you must multiply the read position by the value set next to the **6005-01 Position step setting** object (if the bit 2 **Scaling function** in the **6000-00 Operating parameters** object is enabled = 1).

**EXAMPLE**

We have the following linear encoder: **SMA5-GA-50**.

Scaling function = 0

6501-00 Measuring step = 0000 C350h = 50,000 nm = 0.05 mm

6004-00 Position value = 0001 1005h = 69,637 dec

Position = **6004-00 Position value** * **6501-00 Measuring step** = 0001 1005h * 0000 C350h = CF88 D090h = 3,481,850,000 nm

3,481,850,000 nm = 3,481,850 μm = 3,481.85 mm

**EXAMPLE**

We have the following linear encoder: **SMA5-GA-50**.

Scaling function = 1

6005-01 Position step setting = 0001 86A0h = 100,000 nm = 0.1 mm

6004-00 Position value = 0000 1760h = 5,984 dec

Position = **6004-00 Position value** * **6005-01 Position step setting** = 0000 1760h * 0001 86A0h = 23AA DC00h = 598,400,000 nm

598,400,000 nm = 598,400 μm = 598.4 mm

6005-00 Measuring step setting

[Unsigned8, ro]

This object is intended to show the number of subindexes that are included in the object 6005.

Default = 1h

6005-01 Position step setting

[Unsigned32, rw]

**WARNING**

This object is active only if the bit 2 **Scaling function** in the **6000-00 Operating parameters** object is set to "1"; otherwise it is ignored, the user cannot enter any value in this object and the system uses the physical resolution, see the **2201-00 Lika linear absolute sensor resolution** and **6501-00 Measuring step** objects. As soon as the user confirms the value in the **2201-00 Lika linear absolute sensor resolution** object, the program automatically sets the default value of the **6005-01 Position step setting** and **6501-00 Measuring step** objects accordingly.

Furthermore, if the **Bypass** parameter (see on page 75) is set to "1" = Bypass enabled, the scaling function -even if enabled- is ignored and the position information is outputted as it is.

If the bit 2 **Scaling function** in the **6000-00 Operating parameters** object is set to "0", then **6005-01 Position step setting** = **2201-00 Lika linear absolute sensor resolution**

This object is used to set a custom resolution (otherwise referred to as measuring step) expressed in nanometres [nm].

The resolution can be defined as the smallest change in the underlying quantity that produces a response in the measurement, the response being the information that is provided to output.

The custom resolution value must be greater than or equal to the physical resolution of the connected encoder.

We suggest setting a value that is a multiple of the physical resolution as set next to the **2201-00 Lika linear absolute sensor resolution** object not to cause a counting error, i.e. a jump in the position count when the sensor crosses the physical zero point (see the WARNING below).

Default = according to **2201-00 Lika linear absolute sensor resolution**

Min. value = 0000 03E8h

Max. value = 004C 4B40h

**EXAMPLE**

We need to connect the following linear encoder: **SMA5-GA-50**.

As you can see in the product datasheet, "50" in the order code means a **0.05 mm** resolution = 50,000 nanometres resolution. As soon as the user confirms the value in the **2201-00 Lika linear absolute sensor resolution** object, the system automatically sets the default value of the **6005-01 Position step setting** object accordingly (0000 C350h). If needed, after enabling the **Scaling function** parameter the user is allowed to set a custom resolution: it must be greater than or equal to 0000 C350h.

**EXAMPLE**

We need to connect the following linear encoder: **SMAX-BG-100**.

As you can see in the product datasheet, "100" in the order code means a **0.1 mm** resolution = 100,000 nanometres resolution. As soon as the user confirms the value in the **2201-00 Lika linear absolute sensor resolution** object, the system automatically sets the default value of the **6005-01 Position step setting** object accordingly (0001 86A0h). If needed, after enabling the **Scaling function** parameter the user is allowed to set a custom resolution: it must be greater than or equal to 0001 86A0h.

**WARNING**

When you enable the scaling function (**Scaling function** = 1), a counting error, i.e. a jump in the position count, may occur if the following conditions arise:

- a physical zero setting has been performed in the linear sensor;
- the **6005-01 Position step setting** object value is not a multiple of the physical resolution as set next to the **2201-00 Lika linear absolute sensor resolution** object;
- the measuring range (**6001-00 Total measuring range** and **6002-00 Total measuring range** objects) is not a power of 2 submultiple of the maximum measuring range.

If the above described conditions arise, a counting error may occur when the sensor crosses the physical zero point.

If the scaling function is disabled (**Scaling function** = 0), the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1) yet no physical zero setting has been performed in the linear sensor, the transmitted position values are always consistent.

If the scaling function is enabled (**Scaling function** = 1), the **6005-01 Position step setting** object value is a multiple of the physical resolution and the measuring range is a power of 2 submultiple of the maximum measuring range, the transmitted position values are consistent, regardless of the physical zero setting.

**NOTE**

If you have set and activated the preset, when you change the value next to the **6005-01 Position step setting** object, then you must check the value in the **6003-00 Preset** object and perform the homing operation.

**EXAMPLE**

The main and default features of the **SMAX-BG-100** linear encoder are as follows:

- | | |
|---------------------------------------|-----------------------|
| 1 - Default resolution | = 0.1 mm = 100,000 nm |
| 2 - MTAX max. measuring length | = 600 mm |

3 - **Max. number of information** = 6,000 (13 bits)

As stated, the max. number of information provided to output is calculated as follows:

$$\text{Number of information} = \frac{\text{Max. measuring length}}{\text{Resolution}}$$

Thus, in a default configuration the number of information is:

$$\text{Number of information} = \frac{\text{Max. measuring length}}{\text{Resolution}} = \frac{600}{0.1} = \mathbf{6,000}$$

Let's assume that you need **2,000 information** to be provided to output for the max. measuring length. It follows that you need to calculate and then set a custom resolution.

The resolution value results from the following calculation:

$$\text{Resolution} = \frac{\text{Max. measuring length}}{\text{Number of information}}$$

Thus, in the example the resolution will be:

$$\text{Resolution} = \frac{\text{Max. measuring length}}{\text{Number of information}} = \frac{600}{2,000} = \mathbf{0.3}$$

As the value next to the **6005-01 Position step setting** object has to be expressed in nanometres, then you have to enter the value **300,000**.


The complete programming sequence will be:

1. Enable the **Scaling function: 6000-00 Operating parameters**, bit 2 = 1
2. Set the custom resolution: **6005-01 Position step setting** = 0004 93E0 hex (300,000 dec)
3. Save the set parameters (**1010-01 Store parameters** object; see on page 68)



NOTE

Please note that, if you set a preset along the path, when the encoder moves back and cross the zero, the value immediately after 0 will be 1,999 as shown below.



6500-00 Operating status

[Unsigned16, ro]

Bit	Function	bit = 0	bit = 1
0 and 1	not used		
2	Scaling	Disabled	Enabled
3	Counting direction	Standard	Reversed
4 ... 15	not used		

Scaling

It shows the value that is currently set through the bit 2 **Scaling function** in the **6000-00 Operating parameters** object. In other words, it is intended to show whether the scaling function is enabled or disabled. If the value is "=0" the scaling function is disabled; if the value is "=1" instead the scaling function is enabled. For any further information on setting and using the scaling function refer to the **6000-00 Operating parameters** object on page 77.



NOTE

Please consider that if the **Bypass** parameter (see on page 75) is set to "1" = Bypass enabled, the scaling function -even if enabled- is ignored.

Counting direction

It shows the value that is currently set through the bit 3 **Code sequence** in the **6000-00 Operating parameters** object. If the bit is "=0" the output encoder position value has been set to increase when the sensor moves in the standard direction; if the bit is "=1" instead the output encoder position value has been set to increase when the sensor moves in reverse of the standard direction. For any further information on setting and using the counting direction function refer to the **6000-00 Operating parameters** object on page 77.

6501-00 Measuring step

[Unsigned32, ro]

This object is intended to show the physical resolution of the connected encoder expressed in nanometres [nm]. The physical resolution must be set next to the **2201-00 Lika linear absolute sensor resolution** object. As soon as the user confirms the value in the **2201-00 Lika linear absolute sensor resolution** object, the program automatically sets the value in this object accordingly. If you want to set a custom resolution see the **6005-01 Position step setting** object.

Default = according to **2201-00 Lika linear absolute sensor resolution**

6502-00 Number of revolutions

[Unsigned32, ro]

This register is not used in this application, it is listed for full compliance with the EtherCAT specifications.

Default = 0000 0001h

6503-00 Errors

[Unsigned16, ro]

The corresponding bits of supported errors are set (see the **6504-00 Supported errors** object).

6504-00 Supported errors

[Unsigned16, ro]

This object contains the information on the error alarms supported by the encoder. No error alarms are supported in this encoder.

Default = 0000h (No errors supported).

6505-00 Warnings

[Unsigned16, ro]

The corresponding bits of supported warnings are set (see the **6506-00 Supported warnings** object).

6506-00 Supported warnings

[Unsigned16, ro]

This object contains the information on the warnings supported by the encoder.

bits 0 ... 11 = not supported

bit 12 = wrong parameters loaded from flash memory at power up.

bits 13 ... 15 = not supported

Default = 1000h

6509-00 Offset

[Unsigned32, ro]

As soon as you activate the preset, the current position of the encoder is saved in this object. The offset value is then used in the preset function in order to calculate the encoder position value to be transmitted. To zero set the value in this object you must upload the factory default values (see the [1011-01 Restore default parameters](#) object on page 69).

For any further information on the preset function and the meaning and use of the related objects [6003-00 Preset](#) and [6509-00 Offset](#) refer to page 82.



NOTE

To save the new parameters execute the store parameters function (see the [1010-01 Store parameters](#) object on page 68).

When the power is turned off, parameters not saved are lost.

7.2.6 SDO Abort codes

SDO transfer could be unsuccessful; causes of error are listed and described in the SDO Abort Codes. Here follows the list of the available SDO Abort Codes. For complete information see ETG1000.6 "EtherCAT Specification – Part 6. Application Layer protocol specification", par. 5.6.2.7.2, table 40.

Abort code	Description
0503 0000h	Toggle bit not changed.
0504 0000h	SDO protocol timeout.
0504 0001h	Client/Server command specifier not valid or unknown.
0504 0005h	Out of memory.
0601 0000h	Unsupported access to an object.
0601 0001h	Attempt to read a write only object.
0601 0002h	Attempt to write a read only object.
0602 0000h	The object does not exist in the object dictionary.
0604 0041h	The object cannot be mapped into the PDO.
0604 0042h	The number and length of the objects to be mapped would exceed PDO length.
0604 0043h	General parameter incompatibility reason.
0604 0047h	General internal incompatibility in the device.
0606 0000h	Access failed due to a hardware error.
0607 0010h	Data type does not match, length of service parameter does not match
0607 0012h	Data type does not match, length of service parameter too high
0607 0013h	Data type does not match, length of service parameter too low
0609 0011h	Subindex does not exist.
0609 0030h	Value range of parameter exceeded (only for write access).
0609 0031h	Value of parameter written too high.
0609 0032h	Value of parameter written too low.
0609 0036h	Maximum value is less than minimum value.
0800 0000h	General error
0800 0020h	Data cannot be transferred or stored to the application.
0800 0021h	Data cannot be transferred or stored to the application because of local control.
0800 0022h	Data cannot be transferred or stored to the application because of the present device state.
0800 0023h	Object dictionary dynamic generation fails or no object dictionary is present.

Refer also to the "4.9 Diagnostic LEDs" section on page 26.

7.2.7 Emergency Error Codes

Emergency Service is used by the Server for transmitting diagnostic messages to the client using MailBox; Error Codes are listed and described in the ETG1000.6 "EtherCAT Specification – Part 6. Application Layer protocol specification", par. 5.6.4.2 table 50.

Error Code		Error Register	Diagnostic Data				
Byte (0)	Byte (1)	Byte (2)	Byte (3)	Byte (4)	Byte (5)	Byte (6)	Byte (7)

Error Code	<p>State Transition Errors of state machine: (for detailed description see ETG1000.6 par. 5.6.4.3)</p> <p>A000hex: transition error from PRE-OPERATIONAL to SAFE-OPERATIONAL</p> <p>A001hex: transition error from SAFE-OPERATIONAL to OPERATIONAL</p> <p>Encoder errors:</p> <p>5000hex: Hardware error</p> <p>5001hex: Diagnostic data (wrong parameters loaded from flash memory)</p>
Error Register	EtherCAT state machine current status (ESM)
Diagnostic Data	information about possible error causes (see ETG1000.6 par. 5.6.4.3.2–5).

Refer also to the "4.9 Diagnostic LEDs" section on page 26.

7.2.8 AL Status Error Codes

If the state transition requested by the Master through the "AL Control Register" is unsuccessful, Slave sets to 1 the "Error Indicator Bit" in "AL Status Register" and writes the cause of the error in "AL Status Code Register". Values and descriptions of "AL Status Code" are available in ETG1000.6 "EtherCAT Specification – Part 6. Application Layer protocol specification", par. 5.3.2 Table 11.

7.3 File Over EtherCAT (FoE)

Lika converters for encoders are devices that allow the firmware update using the protocol "File over EtherCAT (FoE)".

For any specification on FoE protocol, please refer to "ETG.1000 EtherCAT Specification" document available at the address www.ethercat.org.

Please refer also to the "6.7 Firmware upgrade" section on page 49.

8 – Default parameters list

Default values are expressed in hexadecimal notation.

Parameters list	Default values		
2200-00 Lika linear absolute sensor setting	0019 1310		
No of SSI clocks	19		
Max No of Information	13		
SSI protocol	1		
SSI output code	0		
Bypass	0		
2201-00 Lika linear absolute sensor resolution	000A		
6000-00 Operating parameters	0000		
Bit 2 Scaling function	0 = Disabled		
Bit 3 Code sequence	0 = Standard		
6001-00 Total measuring range	0008 0000		
6002-00 Total measuring range	0008 0000		
6003-00 Preset	00000 0000		
6005-01 Position step setting	0000 2710		
6501-00 Measuring step	0000 2710		

This page intentionally left blank

Document release	Release date	Description	HW	SW	XML file version
1.0	18.05.2015	First issue	H01	S01	V1
1.1	10.04.2018	General review	H01	S01	V1
1.2	13.09.2021	Bypass function added and related parameters updated	H01	S02	V2
1.3	07.10.2021	Information about encoder power supply added	H01	S02	V2
1.4	04.07.2022	"4.2 SSI connector (Figure 4)" section updated	H01	S02	V2



Dispose separately

lika

Lika Electronic

Via S. Lorenzo, 25 • 36010 Carrè (VI) • Italy

Tel. +39 0445 806600

Fax +39 0445 806699



info@lika.biz • www.lika.biz